

Initial Study and Draft Mitigated Negative Declaration
Lions Park Projects

APPENDIX C

Water Quality Management Plan

Initial Study and Draft Mitigated Negative Declaration
Lions Park Projects



WQ XX-XXXX

**County of Orange/Santa Ana Region
Priority Project
Water Quality Management Plan
(WQMP)**

Project Name:

**Costa Mesa Library and Park Expansion
570 W 18TH STREET, COSTA MESA, CA 92627**

Prepared for:

**The City of Costa Mesa
77 Fair Drive
Costa Mesa, CA 92626
(714) 754-5000**

Prepared by:

**KPFF Consulting Engineers
700 South Flower Street, Suite 2100
Los Angeles, CA 90017
(213) 418-0201**

December 14, 2016

Project Owner's Certification			
Planning Application No. (If applicable)		Grading Permit No.	
Tract/Parcel Map and Lot(s) No.		Building Permit No.	
Address of Project Site and APN (If no address, specify Tract/Parcel Map and Lot Numbers)			

This Water Quality Management Plan (WQMP) has been prepared for The City of Costa Mesa by KPFF Consulting Engineers. The WQMP is intended to comply with the requirements of the County of Orange NPDES Stormwater Program requiring the preparation of the plan.

The undersigned, while it owns the subject property, is responsible for the implementation of the provisions of this plan, including the ongoing operation and maintenance of all best management practices (BMPs), and will ensure that this plan is amended as appropriate to reflect up-to-date conditions on the site consistent with the current Orange County Drainage Area Management Plan (DAMP) and the intent of the non-point source NPDES Permit for Waste Discharge Requirements for the County of Orange, Orange County Flood Control District and the incorporated Cities of Orange County within the Santa Ana Region. Once the undersigned transfers its interest in the property, its successors-in-interest shall bear the aforementioned responsibility to implement and amend the WQMP. An appropriate number of approved and signed copies of this document shall be available on the subject site in perpetuity.

Owner: The City of Costa Mesa			
Title			
Company	City of Costa Mesa		
Address	77 Fair Drive		
Email			
Telephone #	(714) 754-5000		
I understand my responsibility to implement the provisions of this WQMP including the ongoing operation and maintenance of the best management practices (BMPs) described herein.			
Owner Signature		Date	

Water Quality Management Plan (WQMP)
Costa Mesa Library and Park Expansion

Preparer (Engineer):			
Title	Thomas Gsell	PE Registration #	C34734
Company	KPF Consulting Engineers		
Address	700 South Flower Street, Suite 2100, Los Angeles, CA 90017		
Email	thomas.gsell@kpf.com		
Telephone #	213-266-5216		
I hereby certify that this Water Quality Management Plan is in compliance with, and meets the requirements set forth in, Order No. R8-2009-0030/NPDES No. CAS618030, of the Santa Ana Regional Water Quality Control Board.			
Preparer Signature		Date	
Place Stamp Here			

Contents

Page No.

Section I	Permit(s) and Water Quality Conditions of Approval or Issuance	1
Section II	Project Description	3
Section III	Site Description	8
Section IV	Best Management Practices (BMPs)	10
Section V	Inspection/Maintenance Responsibility for BMPs	24
Section VI	BMP Exhibit (Site Plan)	25
Section VII	Educational Materials	26

Attachments

Attachment A	Receiving Waters
Attachment B	303d List
Attachment C	Water Maps
Attachment D	Educational Material
Attachment E	Calculations
Attachment F	Contech Worksheet

Section I Permit(s) and Water Quality Conditions of Approval or Issuance

Provide discretionary or grading/building permit information and water quality conditions of approval, or permit issuance, applied to the project. If conditions are unknown, please request applicable conditions from staff. *Refer to Section 2.1 in the Technical Guidance Document (TGD) available on the OC Planning website (ocplanning.net).*

Project Information	
Permit/Application No. (If applicable)	Grading or Building Permit No. (If applicable)
Address of Project Site (or Tract Map and Lot Number if no address) and APN	1855 Park Avenue, Costa Mesa, CA 92627
Water Quality Conditions of Approval or Issuance	
Water Quality Conditions of Approval or Issuance applied to this project. (Please list verbatim.)	N/A
Conceptual WQMP	
Was a Conceptual Water Quality Management Plan previously approved for this project?	No

Watershed-Based Plan Conditions	
Provide applicable conditions from watershed - based plans including WIHMPs and TMDLS.	N/A

Section II Project Description

II.1 Project Description

Provide a detailed project description including:

- Project areas;
- Land uses;
- Land cover;
- Design elements;
- A general description not broken down by drainage management areas (DMAs).

Include attributes relevant to determining applicable source controls. *Refer to Section 2.2 in the Technical Guidance Document (TGD) for information that must be included in the project description.*

Description of Proposed Project				
Development Category (From Model WQMP, Table 7.11-2; or -3):	Redevelopment Project			
Project Area (ft ²): 155,339	Number of Dwelling Units: 1		SIC Code: 8231	
Project Area	Pervious		Impervious	
	Area (acres or sq ft)	Percentage	Area (acres or sq ft)	Percentage
Pre-Project Conditions	57,195	0.368	98,144	0.632
Post-Project Conditions	77,388	0.498	77,951	0.502
Drainage Patterns/Connections	<p>The proposed drainage includes nine different drainage areas separated into 2 phases. Phase 1 includes drainage area DA1-DA9</p> <p>The proposed drainage patterns include a combination of two systems; local biofiltration with collection and an underground infiltration system. Along the proposed building runoff from the roof will be collected via roof drains and connected into an 18" storm drain pipe that will transfer the runoff into an underground infiltration system. Along the building there are biofiltration areas that will collect local stormwater into a perforated pipe and divert the flow into the main 18" storm drain pipe running through the middle of the</p>			

site. Stormwater that does not fall on the roof or into the biofiltration areas will be collected via area drain and transferred into the main 18" storm drain pipe running through the middle of the property and eventually collected in the underground infiltration system.ocal biofiltration with collection and an underground infiltration system.. Along the proposed building runoff from the roof will be collected via roof drains and connected into an 18" storm drain pipe that will transfer the runoff into an underground infiltration system. Along the building there are biofiltration areas that will collect local stormwater into a perforated pipe and divert the flow into the main 18" storm drain pipe running through the middle of the site. Stormwater that does not fall on the roof or into the biofiltration areas will be collected via area drain and transferred into the main 18" storm drain pipe running through the middle of the property and eventually collected in the underground infiltration system.

<p>Narrative Project Description: (Use as much space as necessary.)</p>	<p>The project is located in the 10 acre Lions Park located at 570 West 18th Street in the City of Costa Mesa, California. The park is bounded by Park Avenue on the east, West 18th Street on the south, Anaheim Avenue on the west, and various City complexes to the north (Costa Mesa Historical Society and Costa Mesa Fire Station Number 3). Two projects are proposed to be completed in two implementation phases.</p> <p>Phase 1 Library and Park Expansion will include a new two-story, 20,000 – 22,000-square foot library with landscape and site development immediately around the building. The park expansion includes demolition of the single story Neighborhood Community Center and creation of new park open space in its place. Other on-site work includes construction of a new 22-car surface parking lot to be located on the west side of the park, in front of the Costa Mesa Historical Society, accessed from Anaheim Avenue. On-site development excluding the building footprint is 2.45 acres. Off-site improvements include parkway reconstruction adjacent to the library and new angled parking adjacent to the park expansion in Park Avenue.</p> <p>Phase 2 Donald Dungan Library Renovation – New Community Meeting Center will include renovation of the existing Donald Dungan Library and limited site development immediately around the existing building.</p>
---	--

Priority Project Water Quality Management Plan (WQMP)
Costa Mesa Library and Park Expansion

II.2 Potential Stormwater Pollutants

Determine and list expected stormwater pollutants based on land uses and site activities. *Refer to Section 2.2.2 and Table 2.1 in the Technical Guidance Document (TGD) for guidance.*

Pollutants of Concern			
Pollutant	Check One for each: E=Expected to be of concern N=Not Expected to be of concern		Additional Information and Comments
Suspended-Solid/ Sediment	E <input checked="" type="checkbox"/>	N <input type="checkbox"/>	
Nutrients	E <input checked="" type="checkbox"/>	N <input type="checkbox"/>	
Heavy Metals	E <input type="checkbox"/>	N <input checked="" type="checkbox"/>	
Pathogens (Bacteria/Virus)	E <input type="checkbox"/>	N <input checked="" type="checkbox"/>	
Pesticides	E <input checked="" type="checkbox"/>	N <input type="checkbox"/>	
Oil and Grease	E <input checked="" type="checkbox"/>	N <input type="checkbox"/>	
Toxic Organic Compounds	E <input checked="" type="checkbox"/>	N <input type="checkbox"/>	
Trash and Debris	E <input checked="" type="checkbox"/>	N <input type="checkbox"/>	

II.3 Hydrologic Conditions of Concern

Determine if streams located downstream from the project area are potentially susceptible to hydromodification impacts. *Refer to Section 2.2.3.1 in the Technical Guidance Document (TGD) for North Orange County or Section 2.2.3.2 for South Orange County.*

No – Show map

Priority Project Water Quality Management Plan (WQMP)
Costa Mesa Library and Park Expansion

Yes – Describe applicable hydrologic conditions of concern below. *Refer to Section 2.2.3 in the Technical Guidance Document (TGD).*

N/A

II.4 Post Development Drainage Characteristics

Describe post development drainage characteristics. *Refer to Section 2.2.4 in the Technical Guidance Document (TGD).*

The proposed drainage patterns include a combination of two systems; local biofiltration with collection and an underground infiltration system. Along the proposed building runoff from the roof will be collected via roof drains and connected into an 18" storm drain pipe that will transfer the runoff into an underground infiltration system. Along the building there are biofiltration areas that will collect local stormwater into a perforated pipe and divert the flow into the main 18" storm drain pipe running through the middle of the site. Stormwater that does not fall on the roof or into the biofiltration areas will be collected via area drain and transferred into the main 18" storm drain pipe running through the middle of the property and eventually collected in the underground infiltration system.

II.5 Property Ownership/Management

Describe property ownership/management. *Refer to Section 2.2.5 in the Technical Guidance Document (TGD).*

The City of Costa Mesa will be the owner.

Section III Site Description

III.1 Physical Setting

Fill out table with relevant information. *Refer to Section 2.3.1 in the Technical Guidance Document (TGD).*

Name of Planned Community/Planning Area (if applicable)	N/A
Location/Address	1855 Park Avenue, Costa Mesa, CA 92627
General Plan Land Use Designation	Institutional
Zoning	I&R – Institutional and Recreational
Acreage of Project Site	3.57
Predominant Soil Type	Type D

III.2 Site Characteristics

Fill out table with relevant information and include information regarding BMP sizing, suitability, and feasibility, as applicable. *Refer to Section 2.3.2 in the Technical Guidance Document (TGD).*

Site Characteristics	
Precipitation Zone	0.75
Topography	Existing library and existing on-site
Drainage Patterns/Connections	The existing drainage pattern has water on the northern parking lot of the property being sheet flowed through a curb and gutter into an existing valley gutter, then water flows into an existing catch basin and eventually connects to the City of Costa Mesa public storm drain system. Water on the

Priority Project Water Quality Management Plan (WQMP)
Costa Mesa Library and Park Expansion

	eastern parking lot is collected via a valley gutter running along the back of the parking stalls and eventually flows out of the eastern driveway on Park Avenue. From there the stormwater follows a curb and gutter running north along Park avenue and eventually enters a curb opening catch basin located at Plumer St. All the water collected on the building are collected via roof drains and is spilled into the existing concrete sidewalk and eventually the water lands on the landscape around the property. Raised planters are located around the building collect water and infiltration this stormwater. Water along the western parking lot is carried via a valley gutter flowing south along the back of the parking stalls and eventually falls on a curb opening catch basin along Anaheim Avenue. Then the water flows on the Costa Mesa public stormdrain system and eventually enters the lower Newport bay and eventually the pacific ocean.
Soil Type, Geology, and Infiltration Properties	D-Soils
Hydrogeologic (Groundwater) Conditions	Depth to groundwater is greater than 50 feet
Geotechnical Conditions (relevant to infiltration)	The proposed infiltration rate is 12 in/hour.
Off-Site Drainage	N/A
Utility and Infrastructure Information	A proposed infiltration system will be used.

III.3 Watershed Description

Fill out table with relevant information and include information regarding BMP sizing, suitability, and feasibility, as applicable. *Refer to Section 2.3.3 in the Technical Guidance Document (TGD).*

Receiving Waters	Lower Newport Bay
303(d) Listed Impairments	Chlordane, DDT(Dichlorodiphenyltrichloroethane), Nutrients, PCBs (Polychlorinated biphenyls), Pesticides,
Applicable TMDLs	Chlordane, Copper, DDT(Dichlorodiphenyltrichloroethane), PCBs (Polychlorinated biphenyls), Sediment Toxicity

Priority Project Water Quality Management Plan (WQMP)
Costa Mesa Library and Park Expansion

Pollutants of Concern for the Project	N/A
Environmentally Sensitive and Special Biological Significant Areas	N/A

Section IV Best Management Practices (BMPs)

IV. 1 Project Performance Criteria

Describe project performance criteria. Several steps must be followed in order to determine what performance criteria will apply to a project. These steps include:

- If the project has an approved WIHMP or equivalent, then any watershed specific criteria must be used and the project can evaluate participation in the approved regional or sub-regional opportunities. (Please ask your assigned planner or plan checker regarding whether your project is part of an approved WIHMP or equivalent.)
- Determine applicable hydromodification control performance criteria. *Refer to Section 7.II-2.4.2.2 of the Model WQMP.*
- Determine applicable LID performance criteria. *Refer to Section 7.II-2.4.3 of the Model WQMP.*
- Determine applicable treatment control BMP performance criteria. *Refer to Section 7.II-3.2.2 of the Model WQMP.*
- Calculate the LID design storm capture volume for the project. *Refer to Section 7.II-2.4.3 of the Model WQMP.*

(NOC Permit Area only) Is there an approved WIHMP or equivalent for the project area that includes more stringent LID feasibility criteria or if there are opportunities identified for implementing LID on regional or sub-regional basis?		YES <input type="checkbox"/>	NO <input checked="" type="checkbox"/>
If yes, describe WIHMP feasibility criteria or regional/sub-regional LID opportunities.	N/A		

Project Performance Criteria	
If HCOC exists, list applicable hydromodification control performance criteria (Section 7.II-2.4.2.2 in MWQMP)	N/A
List applicable LID performance criteria (Section 7.II-2.4.3 from MWQMP)	N/A
List applicable treatment control BMP performance criteria (Section 7.II-3.2.2 from MWQMP)	
Calculate LID design storm capture volume for Project.	

IV.2. Site Design and Drainage

Describe site design and drainage including

- A narrative of site design practices utilized or rationale for not using practices;
- A narrative of how site is designed to allow BMPs to be incorporated to the MEP
- A table of DMA characteristics and list of LID BMPs proposed in each DMA.
- Reference to the WQMP “BMP Exhibit.”
- Calculation of Design Capture Volume (DCV) for each drainage area.
- A listing of GIS coordinates for LID and Treatment Control BMPs.

Refer to Section 2.4.2 in the Technical Guidance Document (TGD).

The proposed drainage patterns include a combination of two systems; local biofiltration with collection and an underground infiltration system. Along the proposed building runoff from the roof will be collected via roof drains and connected into an 18” storm drain pipe that will transfer the runoff into an underground infiltration system. Along the building there are biofiltration areas that will collect local stormwater into a perforated pipe and divert the flow into the main 18” storm drain pipe running through the middle of the site. Stormwater that does not fall on the roof or into the biofiltration areas will be collected via area drain and transferred into the main 18” storm drain pipe running through the middle of the property and eventually collected in the underground infiltration system.

IV.3 LID BMP Selection and Project Conformance Analysis

Each sub-section below documents that the proposed design features conform to the applicable project performance criteria via check boxes, tables, calculations, narratives, and/or references to worksheets. Refer to Section 2.4.2.3 in the Technical Guidance Document (TGD) for selecting LID BMPs and Section 2.4.3 in the Technical Guidance Document (TGD) for conducting conformance analysis with project performance criteria.

IV.3.1 Hydrologic Source Controls (HSCs)

If required HSCs are included, fill out applicable check box forms. If the retention criteria are otherwise met with other LID BMPs, include a statement indicating HSCs not required.

Name	Included?
Localized on-lot infiltration	<input type="checkbox"/>
Impervious area dispersion (e.g. roof top disconnection)	<input type="checkbox"/>
Street trees (canopy interception)	<input type="checkbox"/>
Residential rain barrels (not actively managed)	<input type="checkbox"/>
Green roofs/Brown roofs	<input type="checkbox"/>
Blue roofs	<input type="checkbox"/>
Impervious area reduction (e.g. permeable pavers, site design)	<input type="checkbox"/>
Other:	<input type="checkbox"/>

IV.3.2 Infiltration BMPs

Identify infiltration BMPs to be used in project. If design volume cannot be met, state why.

Name	Included?
Bioretention without underdrains	<input type="checkbox"/>
Rain gardens	<input type="checkbox"/>
Porous landscaping	<input type="checkbox"/>
Infiltration planters	<input type="checkbox"/>
Retention swales	<input type="checkbox"/>
Infiltration trenches	<input type="checkbox"/>
Infiltration basins	<input type="checkbox"/>
Drywells	<input type="checkbox"/>
Subsurface infiltration galleries	<input checked="" type="checkbox"/>
French drains	<input type="checkbox"/>
Permeable asphalt	<input type="checkbox"/>
Permeable concrete	<input type="checkbox"/>
Permeable concrete pavers	<input type="checkbox"/>
Other:	<input type="checkbox"/>
Other:	<input type="checkbox"/>

Show calculations below to demonstrate if the LID Design Storm Capture Volume can be met with infiltration BMPs. If not, document how much can be met with infiltration and document why it is not feasible to meet the full volume with infiltration BMPs.

Calculations are shown in Appendix E

IV.3.3 Evapotranspiration, Rainwater Harvesting BMPs

If the full Design Storm Capture Volume cannot be met with infiltration BMPs, describe any evapotranspiration and/or rainwater harvesting BMPs included.

Name	Included?
All HSCs; <i>See Section IV.3.1</i>	<input type="checkbox"/>
Surface-based infiltration BMPs	<input type="checkbox"/>
Biotreatment BMPs	<input type="checkbox"/>
Above-ground cisterns and basins	<input type="checkbox"/>
Underground detention	<input type="checkbox"/>
Other:	<input type="checkbox"/>
Other:	<input type="checkbox"/>
Other:	<input type="checkbox"/>

Priority Project Water Quality Management Plan (WQMP)
Costa Mesa Library and Park Expansion

Show calculations below to demonstrate if the LID Design Storm Capture Volume can be met with evapotranspiration and/or rainwater harvesting BMPs in combination with infiltration BMPs. If not, document below how much can be met with either infiltration BMPs, evapotranspiration, rainwater harvesting BMPs, or a combination, and document why it is not feasible to meet the full volume with these BMP categories.

N/A

IV.3.4 Biotreatment BMPs

If the full Design Storm Capture Volume cannot be met with infiltration BMPs, and/or evapotranspiration and rainwater harvesting BMPs, describe biotreatment BMPs included. Include sections for selection, suitability, sizing, and infeasibility, as applicable.

Name	Included?
Bioretention with underdrains	<input type="checkbox"/>
Stormwater planter boxes with underdrains	<input type="checkbox"/>
Rain gardens with underdrains	<input type="checkbox"/>
Constructed wetlands	<input type="checkbox"/>
Vegetated swales	<input type="checkbox"/>
Vegetated filter strips	<input type="checkbox"/>
Proprietary vegetated biotreatment systems	<input type="checkbox"/>
Wet extended detention basin	<input type="checkbox"/>
Dry extended detention basins	<input type="checkbox"/>
Other:	<input type="checkbox"/>
Other:	<input type="checkbox"/>

Show calculations below to demonstrate if the LID Design Storm Capture Volume can be met with infiltration, evapotranspiration, rainwater harvesting and/or biotreatment BMPs. If not, document how much can be met with either infiltration BMPs, evapotranspiration, rainwater harvesting BMPs, or a combination, and document why it is not feasible to meet the full volume with these BMP categories.

N/A

IV.3.5 Hydromodification Control BMPs

Describe hydromodification control BMPs. *See Section 5 of the Technical Guidance Document (TGD).* Include sections for selection, suitability, sizing, and infeasibility, as applicable. Detail compliance with Prior Conditions of Approval (if applicable).

Hydromodification Control BMPs	
BMP Name	BMP Description

IV.3.6 Regional/Sub-Regional LID BMPs

Describe regional/sub-regional LID BMPs in which the project will participate. *Refer to Section 7.II-2.4.3.2 of the Model WQMP.*

Regional/Sub-Regional LID BMPs
N/A

IV.3.7 Treatment Control BMPs

Treatment control BMPs can only be considered if the project conformance analysis indicates that it is not feasible to retain the full design capture volume with LID BMPs. Describe treatment control BMPs including sections for selection, sizing, and infeasibility, as applicable.

Treatment Control BMPs	
BMP Name	BMP Description

Priority Project Water Quality Management Plan (WQMP)
Costa Mesa Library and Park Expansion

IV.3.8 Non-structural Source Control BMPs

Fill out non-structural source control check box forms or provide a brief narrative explaining if non-structural source controls were not used.

Non-Structural Source Control BMPs				
Identifier	Name	Check One		If not applicable, state brief reason
		Included	Not Applicable	
N1	Education for Property Owners, Tenants and Occupants	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
N2	Activity Restrictions	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No CCR are proposed
N3	Common Area Landscape Management	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
N4	BMP Maintenance	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
N5	Title 22 CCR Compliance (How development will comply)	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No hazardous waste from this project
N6	Local Industrial Permit Compliance	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No local water quality ordinance
N7	Spill Contingency Plan	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No hazardous waste from this property
N8	Underground Storage Tank Compliance	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No underground storage tank within the project boundary
N9	Hazardous Materials Disclosure Compliance	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No hazardous waste from this project.
N10	Uniform Fire Code Implementation	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No fire code implementation.
N11	Common Area Litter Control	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
N12	Employee Training	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
N13	Housekeeping of Loading Docks	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No loading docks are proposed for this project.
N14	Common Area Catch Basin Inspection	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
N15	Street Sweeping Private Streets and Parking Lots	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
N16	Retail Gasoline Outlets	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No gasoline outlets are proposed for this project.

Priority Project Water Quality Management Plan (WQMP)
Costa Mesa Library and Park Expansion

IV.3.9 Structural Source Control BMPs

Fill out structural source control check box forms or provide a brief narrative explaining if structural source controls were not used.

Structural Source Control BMPs				
Identifier	Name	Check One		If not applicable, state brief reason
		Included	Not Applicable	
S1	Provide storm drain system stenciling and signage	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
S2	Design and construct outdoor material storage areas to reduce pollution introduction	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No hazardous material is proposed for this project.
S3	Design and construct trash and waste storage areas to reduce pollution introduction	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
S4	Use efficient irrigation systems & landscape design, water conservation, smart controllers, and source control	<input checked="" type="checkbox"/>	<input type="checkbox"/>	
S5	Protect slopes and channels and provide energy dissipation	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No protected slopes in this project.
	Incorporate requirements applicable to individual priority project categories (from SDRWQCB NPDES Permit)	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No requirements from SDRWQCB.
S6	Dock areas	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No dock areas in this project.
S7	Maintenance bays	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No maintenance bays in this project.
S8	Vehicle wash areas	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No vehicle wash areas in this project.
S9	Outdoor processing areas	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No outdoor processing areas in this project.
S10	Equipment wash areas	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No equipment wash areas in this project.
S11	Fueling areas	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No fueling areas in this project.
S12	Hillside landscaping	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No hill side landscaping in this project.
S13	Wash water control for food preparation areas	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No food preparation areas in this project.
S14	Community car wash racks	<input type="checkbox"/>	<input checked="" type="checkbox"/>	No community car wash racks in this project.

IV.4 Alternative Compliance Plan (If Applicable)

Describe an alternative compliance plan (if applicable). Include alternative compliance obligations (i.e., gallons, pounds) and describe proposed alternative compliance measures. *Refer to Section 7.II 3.0 in the WQMP.*

IV.4.1 Water Quality Credits

Determine if water quality credits are applicable for the project. *Refer to Section 3.1 of the Model WQMP for description of credits and Appendix VI of the Technical Guidance Document (TGD) for calculation methods for applying water quality credits.*

Description of Proposed Project				
Project Types that Qualify for Water Quality Credits (Select all that apply):				
<input checked="" type="checkbox"/> Redevelopment projects that reduce the overall impervious footprint of the project site.	<input type="checkbox"/> Brownfield redevelopment, meaning redevelopment, expansion, or reuse of real property which may be complicated by the presence or potential presence of hazardous substances, pollutants or contaminants, and which have the potential to contribute to adverse ground or surface WQ if not redeveloped.	<input type="checkbox"/> Higher density development projects which include two distinct categories (credits can only be taken for one category): those with more than seven units per acre of development (lower credit allowance); vertical density developments, for example, those with a Floor to Area Ratio (FAR) of 2 or those having more than 18 units per acre (greater credit allowance).		
<input type="checkbox"/> Mixed use development, such as a combination of residential, commercial, industrial, office, institutional, or other land uses which incorporate design principles that can demonstrate environmental benefits that would not be realized through single use projects (e.g. reduced vehicle trip traffic with the potential to reduce sources of water or air pollution).		<input type="checkbox"/> Transit-oriented developments, such as a mixed use residential or commercial area designed to maximize access to public transportation; similar to above criterion, but where the development center is within one half mile of a mass transit center (e.g. bus, rail, light rail or commuter train station). Such projects would not be able to take credit for both categories, but may have greater credit assigned		<input type="checkbox"/> Redevelopment projects in an established historic district, historic preservation area, or similar significant city area including core City Center areas (to be defined through mapping).
<input type="checkbox"/> Developments with dedication of undeveloped portions to parks, preservation areas and other pervious uses.	<input type="checkbox"/> Developments in a city center area.	<input type="checkbox"/> Developments in historic districts or historic preservation areas.	<input type="checkbox"/> Live-work developments, a variety of developments designed to support residential and vocational needs together – similar to criteria to mixed use development; would not be able to take credit for both categories.	<input type="checkbox"/> In-fill projects, the conversion of empty lots and other underused spaces into more beneficially used spaces, such as residential or commercial areas.

Calculation of Water Quality Credits (if applicable)	N/A
---	-----

IV.4.2 Alternative Compliance Plan Information

Describe an alternative compliance plan (if applicable). Include alternative compliance obligations (i.e., gallons, pounds) and describe proposed alternative compliance measures. *Refer to Section 7.II 3.0 in the Model WQMP.*

N/A

Section V Inspection/Maintenance Responsibility for BMPs

Fill out information in table below. Prepare and attach an Operation and Maintenance Plan. Identify the funding mechanism through which BMPs will be maintained. Inspection and maintenance records must be kept for a minimum of five years for inspection by the regulatory agencies. *Refer to Section 7.II 4.0 in the Model WQMP.*

BMP Inspection/Maintenance			
BMP	Reponsible Party(s)	Inspection/Maintenance Activities Required	Minimum Frequency of Activities
Contech Infiltration System	The City of Costa Mesa	Before and after a major storm event; before and after the wet season	Yearly

Section VI BMP Exhibit (Site Plan)

VI.1 BMP Exhibit (Site Plan)

Include a BMP Exhibit (Site Plan), at a size no less than 24" by 36," which includes the following minimum information:

- Insert in the title block (lower right hand corner) of BMP Exhibit: the WQMP Number (assigned by staff) and the grading/building or Planning Application permit numbers
- Project location (address, tract/lot number(s), etc.)
- Site boundary
- Land uses and land covers, as applicable
- Suitability/feasibility constraints
- Structural BMP locations
- Drainage delineations and flow information
- Delineate the area being treated by each structural BMP
- GIS coordinates for LID and Treatment Control BMPs
- Drainage connections
- BMP details
- Preparer name and stamp

Please do not include any areas outside of the project area or any information not related to drainage or water quality. The approved BMP Exhibit (Site Plan) shall be submitted as a plan sheet on all grading and building plan sets submitted for plan check review and approval. The BMP Exhibit shall be at the same size as the rest of the plan sheets in the submittal and shall have an approval stamp and signature prior to plan check submittal.

VI.2 Submittal and Recordation of Water Quality Management Plan

Following approval of the Final Project-Specific WQMP, three copies of the approved WQMP (including BMP Exhibit, Operations and Maintenance (O&M) Plan, and Appendices) shall be submitted. In addition, these documents shall be submitted in a PDF format.



Each approved WQMP (including BMP Exhibit, Operations and Maintenance (O&M) Plan, and Appendices) shall be recorded in the Orange County Clerk-Recorder's Office, prior to close-out of grading and/or building permit. Educational Materials are not required to be included.

Section VII Educational Materials

Refer to the Orange County Stormwater Program (ocwatersheds.com) for a library of materials available. Please only attach the educational materials specifically applicable to this project. Other materials specific to the project may be included as well and must be attached.

Education Materials			
Residential Material (http://www.ocwatersheds.com)	Check If Applicable	Business Material (http://www.ocwatersheds.com)	Check If Applicable
The Ocean Begins at Your Front Door	<input checked="" type="checkbox"/>	Tips for the Automotive Industry	<input type="checkbox"/>
Tips for Car Wash Fund-raisers	<input type="checkbox"/>	Tips for Using Concrete and Mortar	<input type="checkbox"/>
Tips for the Home Mechanic	<input type="checkbox"/>	Tips for the Food Service Industry	<input type="checkbox"/>
Homeowners Guide for Sustainable Water Use	<input type="checkbox"/>	Proper Maintenance Practices for Your Business	<input checked="" type="checkbox"/>
Household Tips	<input type="checkbox"/>	Other Material	Check If Attached
Proper Disposal of Household Hazardous Waste	<input type="checkbox"/>		
Recycle at Your Local Used Oil Collection Center (North County)	<input type="checkbox"/>		<input type="checkbox"/>
Recycle at Your Local Used Oil Collection Center (Central County)	<input type="checkbox"/>		<input type="checkbox"/>
Recycle at Your Local Used Oil Collection Center (South County)	<input type="checkbox"/>		<input type="checkbox"/>
Tips for Maintaining a Septic Tank System	<input type="checkbox"/>		<input type="checkbox"/>
Responsible Pest Control	<input type="checkbox"/>		<input type="checkbox"/>
Sewer Spill	<input type="checkbox"/>		<input type="checkbox"/>
Tips for the Home Improvement Projects	<input type="checkbox"/>		<input type="checkbox"/>
Tips for Horse Care	<input type="checkbox"/>		<input type="checkbox"/>
Tips for Landscaping and Gardening	<input checked="" type="checkbox"/>		<input type="checkbox"/>
Tips for Pet Care	<input type="checkbox"/>		<input type="checkbox"/>
Tips for Pool Maintenance	<input type="checkbox"/>		<input type="checkbox"/>
Tips for Residential Pool, Landscape and Hardscape Drains	<input type="checkbox"/>		<input type="checkbox"/>
Tips for Projects Using Paint	<input type="checkbox"/>		<input type="checkbox"/>

Attachment A



NOTICE

The drainage information has been prepared for information purposes only. The location, ownership, facility information and limits have been determined from available information provided by public agencies, but may not be exact, accurate, or up-to-date. The user of this information is responsible for verifying exact location, ownership, accuracy, and the regional versus local character of drainage facilities.

Additional information may be obtained from public plans and recorded deeds. Facility designations included with this information are for convenience only and are not controlling or intended to imply ownership by the County or the Orange County Flood Control District (OCFCD). The information is being provided as a courtesy and neither the County of Orange nor OCFCD assume any liabilities for inaccuracy of the information.

To notify OC Public Works Flood Control Section of additions or corrections, please contact Sal Gutierrez at (714) 834-5396 or by email at sal.gutierrez@ocpw.ocgov.com

ORANGE COUNTY FLOOD CONTROL DISTRICT			
BASE MAP OF DRAINAGE FACILITIES IN ORANGE COUNTY			
REVISION S. GUTIERREZ	DATE JAN/2000	SHEET NO. 54	DWG. NO. MAPS-113-3

- Channel Drainage Area Boundary
 - Major Sub-Area Drainage Boundary
 - Minor Sub-Area Drainage Boundary
 - Existing O.C.F.C.D. Facility
 - Existing Local Facility
 - Existing Retarding Basin or Reservoir
 - Natural Watercourse
 - City Limits
 - Greenbelt
 - Pump Station
 - Catch Basin (length in feet)
 - Drop Inlet or Other Entry
 - OCFCD Basins or Reservoirs
- Ownership (If other than City or County): Private = P State = S Federal = F


- EXISTING FACILITIES**
- | | | | | | |
|--|-------------------|--|--------------|--|--|
| | O.C.F.C.D. | | LOCAL | | Earth Trapezoidal Channel (base width by height in feet) |
| | | | | | Reinforced Concrete Trapezoidal Channel (base width by height in feet) |
| | | | | | Reinforced Concrete Rectangular Channel (base width by height in feet) |
| | | | | | Reinforced Concrete Box (RCB) (number of barrels-span by height in feet) |
| | | | | | Reinforced Concrete Pipe (RCP) (diameter in inches) |
| | | | | | Metal Sheet Channel (MSC) (Base width by pile height in feet. Sheet pile total length) |
| | | | | | Corrugated Metal Pipe (CMP) (diameter in inches) |
| | | | | | Concrete Pipe (diameter in inches) |
| | | | | | Concrete Oval Pipe (width by height in inches) |
| | | | | | Steel Pipe (diameter in inches) |
| | | | | | Reinforced Concrete Arch (base span by height in inches) |
| | | | | | Corrugated Metal Arch (base span by height in inches) |

Attachment B

REGION	REGION NAME	WATER BODY NAME	WBID	WATER BODY TYPE	WATER BODY TYPE CODE	INTEGRATED REPORT CATEGORY	USGS CATALOGING UNIT	CALWATER WATERSHED	ESTIMATED SIZE AFFECTED	UNIT	POLLUTANT	POLLUTANT CATEGORY	FINAL LISTING DECISION	TMDL REQUIREMENT STATUS	EXPECTED TMDL COMPLETION DATE	EXPECTED ATTAINMENT DATE	USEPA TMDL APPROVED DATE	COMMENTS INCLUDED ON 303(d) LIST	POTENTIAL SOURCES	SOURCE CATEGORY
8	Regional Board 8 - Santa Ana Region	Newport Bay, Lower (entire lower bay, including Rhine Channel, Turning Basin and South Lido Channel to east end of H-J Moorings)	CAB8011400019990322141859	Bay & Harbor	B	5	1807020	80114000	767	Acres	Chlordane	Pesticides	List on 303(d) list (TMDL required list)	5A	2019				Source Unknown	Source Unknown
8	Regional Board 8 - Santa Ana Region	Newport Bay, Lower (entire lower bay, including Rhine Channel, Turning Basin and South Lido Channel to east end of H-J Moorings)	CAB8011400019990322141859	Bay & Harbor	B	5	1807020	80114000	767	Acres	Copper	Metals/Metalloids	Do Not Delist from 303(d) list (TMDL required list)	5A	2007				Source Unknown	Source Unknown
8	Regional Board 8 - Santa Ana Region	Newport Bay, Lower (entire lower bay, including Rhine Channel, Turning Basin and South Lido Channel to east end of H-J Moorings)	CAB8011400019990322141859	Bay & Harbor	B	5	1807020	80114000	767	Acres	DDT (Dichlorodiphenyltrichloroethane)	Pesticides	List on 303(d) list (TMDL required list)	5A	2019				Source Unknown	Source Unknown
8	Regional Board 8 - Santa Ana Region	Newport Bay, Lower (entire lower bay, including Rhine Channel, Turning Basin and South Lido Channel to east end of H-J Moorings)	CAB8011400019990322141859	Bay & Harbor	B	5	1807020	80114000	767	Acres	Indicator Bacteria	Pathogens	Do Not Delist from 303(d) list (being addressed with USEPA approved TMDL)	5B			2/28/2000		Source Unknown	Source Unknown
8	Regional Board 8 - Santa Ana Region	Newport Bay, Lower (entire lower bay, including Rhine Channel, Turning Basin and South Lido Channel to east end of H-J Moorings)	CAB8011400019990322141859	Bay & Harbor	B	5	1807020	80114000	767	Acres	Nutrients	Nutrients	List on 303(d) list (being addressed by USEPA approved TMDL)	5B			1/1/1999		Source Unknown	Source Unknown
8	Regional Board 8 - Santa Ana Region	Newport Bay, Lower (entire lower bay, including Rhine Channel, Turning Basin and South Lido Channel to east end of H-J Moorings)	CAB8011400019990322141859	Bay & Harbor	B	5	1807020	80114000	767	Acres	PCBs (Polychlorinated biphenyls)	Other Organics	List on 303(d) list (TMDL required list)	5A	2019				Source Unknown	Source Unknown
8	Regional Board 8 - Santa Ana Region	Newport Bay, Lower (entire lower bay, including Rhine Channel, Turning Basin and South Lido Channel to east end of H-J Moorings)	CAB8011400019990322141859	Bay & Harbor	B	5	1807020	80114000	767	Acres	Pesticides	Pesticides	List on 303(d) list (being addressed by USEPA approved TMDL)	5B			1/1/2004		Agriculture	Agriculture
8	Regional Board 8 - Santa Ana Region	Newport Bay, Lower (entire lower bay, including Rhine Channel, Turning Basin and South Lido Channel to east end of H-J Moorings)	CAB8011400019990322141859	Bay & Harbor	B	5	1807020	80114000	767	Acres	Pesticides	Pesticides	List on 303(d) list (being addressed by USEPA approved TMDL)	5B			1/1/2004		Contaminated Sediments	Sediment
8	Regional Board 8 - Santa Ana Region	Newport Bay, Lower (entire lower bay, including Rhine Channel, Turning Basin and South Lido Channel to east end of H-J Moorings)	CAB8011400019990322141859	Bay & Harbor	B	5	1807020	80114000	767	Acres	Sediment Toxicity	Toxicity	Do Not Delist from 303(d) list (TMDL required list)	5A	2019				Source Unknown	Source Unknown

Attachment C

SUBJECT TO FURTHER REVISION



LEGEND


- Orange County Precipitation Stations
- 24 Hour, 85th Percentile Rainfall (Inches)
- - - 24 Hour, 85th Percentile Rainfall (Inches) - Extrapolated
- City Boundaries

Rainfall Zones

Design Capture Storm Depth (inches)

- 0.65"
- 0.7
- 0.75
- 0.80
- 0.85
- 0.90
- 0.95
- 1.00
- 1.10"

Note: Events defined as 24-hour periods (calendar days) with greater than 0.1 inches of rainfall.
For areas outside of available data coverage, professional judgment shall be applied.



RAINFALL ZONES

ORANGE COUNTY
TECHNICAL GUIDANCE
DOCUMENT

ORANGE CO. CA

SCALE 1" = 1.8 miles

DESIGNED	TH
DRAWING	TH
CHECKED	BMP
DATE	04/22/10
JOB NO.	9526-E

FIGURE
XVI-1

P:\9526E\6-GIS\Mxd\Reports\Infiltration\Feasibility_20110215\9526E_FigureXVI-1_RainfallZones_20110215.mxd

SUBJECT TO FURTHER REVISION

LEGEND


-  City Boundaries
-  OCWD Groundwater Basin Protection Boundary

Depth To Groundwater


-  ≤ 5'
-  5-10'

Note: Data are not available for South Orange County at this time.

Source:
 Sprotte, Fuller and Greenwood, 1980.
 California Division of Mines and Geology;
 California Geological Survey



Project Location



<p>TITLE</p> <p style="writing-mode: vertical-rl; transform: rotate(180deg);">NORTH ORANGE COUNTY MAPPED SHALLOW GROUNDWATER</p>	
<p>ORANGE COUNTY INFILTRATION STUDY</p>	
<p>ORANGE CO. CA</p>	
<p>JOB</p> <p>SCALE 1" = 1.25 miles</p>	<p>DESIGNED TH</p> <p>DRAWING TH</p> <p>CHECKED BMP</p> <p>DATE 02/09/11</p> <p>JOB NO. 9526-E</p>
	
<p>FIGURE</p> <p style="font-size: 24pt;">XVI-2e</p>	

P:\9526E\6-GIS\Mxd\Reports\InfiltrationFeasibility_20110215\9526E_FigureXVI-2e_DepthToGroundwater15ft_20110215.mxd


SUBJECT TO FURTHER REVISION

LEGEND

- City Boundaries
- Hydrologic Soil Groups**
- A Soils
- B Soils
- C Soils
- D Soils

Source:
 Soils: Natural Resources Conservation Service (NRCS)
 Soil Survey - soil_ca678, Orange County & Western Riverside
 Date of publication: 2006-02-08
<http://websoilsurvey.nrcs.usda.gov/app/HomePage.htm>


Project Location



TITLE: NRCS HYDROLOGIC SOILS GROUPS
 JOB: ORANGE COUNTY INFILTRATION STUDY
 SCALE: 1" = 1.8 miles
 DESIGNED: TH
 DRAWING: TH
 CHECKED: BMP
 DATE: 02/09/11
 JOB NO.: 9526-E
 ORANGE CO. CA

FIGURE XVI-2a

P:\9526E\6-GIS\Mxd\Reports\InfiltrationFeasibility_20110215\9526E_FigureXVI-2a_HydroSoils_20110215.mxd



Susceptibility

- Potential Areas of Erosion, Habitat, & Physical Structure Susceptibility

Channel Type

- Earth (Unstable)
- Earth (Stabilized)
- Stabilized

Tidel Influence


- <= Mean High Water Line (4.28')

Water Body


- Basin
- Dam
- Lake
- Reservoir

Other Lands

- Airport/Military



Project Location



TITLE
**SUSCEPTIBILITY ANALYSIS
 NEWPORT BAY-
 NEWPORT COASTAL STREAMS**

JOB
**ORANGE COUNTY
 WATERSHED
 MASTER PLANNING**
 ORANGE CO. CA


SCALE	1" = 12000'
DESIGNED	TH
DRAWING	TH
CHECKED	BMP
DATE	04/30/10
JOB NO.	9526 E



FIGURE
4

P:\9526E\6-GIS\MapDocs\Susceptibility\Maps_20100505\9526E_NewportBaySusceptibility_20100430.mxd

SUBJECT TO FURTHER REVISION



LEGEND


- Orange County Precipitation Stations
- 24 Hour, 85th Percentile Rainfall (Inches)
- - - 24 Hour, 85th Percentile Rainfall (Inches) - Extrapolated
- City Boundaries

Rainfall Zones

Design Capture Storm Depth (inches)

- 0.65"
- 0.7
- 0.75
- 0.80
- 0.85
- 0.90
- 0.95
- 1.00
- 1.10"

Note: Events defined as 24-hour periods (calendar days) with greater than 0.1 inches of rainfall.
For areas outside of available data coverage, professional judgment shall be applied.



RAINFALL ZONES

ORANGE COUNTY
TECHNICAL GUIDANCE
DOCUMENT

ORANGE CO. CA

SCALE	1" = 1.8 miles
DESIGNED	TH
DRAWING	TH
CHECKED	BMP
DATE	04/22/10
JOB NO.	9526-E

FIGURE
XVI-1

P:\9526E\GIS\MapDocs\Reports\Infiltration\Feasibility_20110215\9526E_FigureXVI-1_RainfallZones_20110215.mxd

SUBJECT TO FURTHER REVISION

LEGEND



- City Boundaries
- OCWD Groundwater Basin Protection Boundary

Depth To Groundwater

- ≤ 5'
- 5-10'

Note: Data are not available for South Orange County at this time.


Source:
 Sprotte, Fuller and Greenwood, 1980.
 California Division of Mines and Geology;
 California Geological Survey



P:\9526E\6-GIS\Mxd\Reports\Infiltration\Feasibility_20110215\9526E_FigureXVI-2e_DepthToGroundwater15ft_20110215.mxd

TITLE		NORTH ORANGE COUNTY MAPPED SHALLOW GROUNDWATER	
JOB		ORANGE COUNTY INFILTRATION STUDY	
SCALE 1" = 1.25 miles		ORANGE CO.	
DESIGNED TH	CHECKED BMP	CA	
DRAWING TH	DATE 02/09/11		
JOB NO. 9526-E			
		FIGURE	
		XVI-2e	

SUBJECT TO FURTHER REVISION




LEGEND

- City Boundaries

Hydrologic Soil Groups

- A Soils
- B Soils
- C Soils
- D Soils

Source:
 Soils: Natural Resources Conservation Service (NRCS)
 Soil Survey - soil_ca678, Orange County & Western Riverside
 Date of publication: 2006-02-08
<http://websoilsurvey.nrcs.usda.gov/app/HomePage.htm>




TITLE: NRCS HYDROLOGIC SOILS GROUPS
 JOB: ORANGE COUNTY INFILTRATION STUDY
 SCALE: 1" = 1.8 miles
 DESIGNED: TH
 DRAWING: TH
 CHECKED: BMP
 DATE: 02/09/11
 JOB NO.: 9526-E
 ORANGE CO. CA



FIGURE XVI-2a

P:\9526E\6-GIS\Mxd\Reports\Infiltration\Feasibility_20110215\9526E_FigureXVI-2a_HydroSoils_20110215.mxd



Susceptibility

- Potential Areas of Erosion, Habitat, & Physical Structure Susceptibility

Channel Type

- Earth (Unstable)
- Earth (Stabilized)
- Stabilized

Tidel Influence


- <= Mean High Water Line (4.28')

Water Body


- Basin
- Dam
- Lake
- Reservoir

Other Lands

- Airport/Military



Project Location



TITLE
**SUSCEPTIBILITY ANALYSIS
 NEWPORT BAY-
 NEWPORT COASTAL STREAMS**

JOB
**ORANGE COUNTY
 WATERSHED
 MASTER PLANNING**

SCALE 1" = 12000'

DESIGNED	TH
DRAWING	TH
CHECKED	BMP
DATE	04/30/10
JOB NO.	9526 E



FIGURE
4

P:\9526E\6-GIS\Mxd\Susceptibility\Maps_20100505\9526E_NewportBaySusceptibility_20100430.mxd

Attachment D

IC3. BUILDING MAINTENANCE

Pollution Prevention

Consider pollution prevention measures at all times for improving pollution control. Implementation of pollution prevention measures may reduce or eliminate the need to implement other more costly or complicated procedures.

The following pollution prevention principles apply to most industries:

- Affirmative Procurement - Use alternative, safer, or recycled products.
- Redirect storm water flows away from areas of concern.
- Reduce use of water or use dry methods.
- Reduce storm water flow across facility site.
- Recycle and reuse waste products and waste flows.
- Move or cover potential pollution from storm water contact.
- Provide on-going employee training in pollution prevention.

1. Properly collect and dispose of water when pressure washing buildings, rooftops, and other large objects.
 2. Properly prepare work area before conducting building maintenance.
 3. Properly clean and dispose of equipment and wastes used and generated during building maintenance.
 4. Employ soil erosion and stabilization techniques when exposing large areas of soil.
 5. Store toxic material under cover when not in use and during precipitation events.
 6. Properly dispose of fluids from air conditioning, cooling tower, and condensate drains.
 7. Regularly inspect air emission control equipment under AQMD permit.
 8. Train employees on these BMPs, storm water discharge prohibitions, and wastewater discharge requirements.
- OPTIONAL:
9. Switch to non-toxic chemicals for maintenance when possible.
 10. Use chemicals that can be recycled.

Best Management Practices

- 1. Properly collect and dispose of water when pressure washing buildings, rooftops, and other large objects.**
 - If pressure washing where the surrounding area is paved, use a water collection device that enables collection of wash water and associated solids. Use a sump pump, wet vacuum or similarly effective device to collect the runoff and loose materials. Dispose of the collected runoff and solids properly.
 - If pressure washing on a grassed area (with or without soap), runoff must be dispersed as sheet flow as much as possible, rather than as a concentrated stream. The wash runoff must remain on the grass and not drain to pavement.
- 2. Properly prepare work area before conducting building maintenance.**
 - Use ground or drop cloths underneath outdoor painting, scraping, and sandblasting work, and properly dispose of collected material daily.
 - Use a ground cloth or oversized tub for activities such as paint mixing and tool cleaning.
 - Use a storm drain cover, filter fabric, or similarly effective runoff control mechanism if dust, grit, wash water, or other pollutants may escape the work area and enter a storm drain.
- 3. Properly clean and dispose of equipment and wastes used and generated during building maintenance.**
 - Clean paint brushes and tools covered with water-based paints in sinks connected to sanitary sewers or in portable containers that can be dumped into a sanitary sewer

drain. Brushes and tools covered with non-water-based paints, finishes, or other materials must be cleaned in a manner that enables collection of used solvents (e.g., paint thinner, turpentine, etc.) for recycling or proper disposal.

- Properly dispose of wash water, sweepings, and sediments.
- Properly store equipment, chemicals, and wastes.
- Do not dump any toxic substance or liquid waste on the pavement, the ground, or toward a storm drain.

OPTIONAL:

- Recycle residual paints, solvents, lumber, and other materials to the maximum extent practicable

- 4. Employ soil erosion and stabilization techniques when exposing large areas of soil.**
 - Confine excavated materials to pervious surfaces away from storm drain inlets, sidewalks, pavement, and ditches. Material must be covered if rain is expected.
 - Use chemical stabilization or geosynthetics to stabilize bare ground surfaces.
- 5. Store toxic material under cover when not in use and during precipitation events.**
- 6. Properly dispose of fluids from air conditioning, cooling tower, and condensate drains.**
- 7. Regularly inspect air emission control equipment under AQMD permit.**

8. Training

- 1. Train employees on these BMPs, storm water discharge prohibitions, and wastewater discharge requirements.**
- 2. Train employees on proper spill containment and cleanup.**
 - Establish training that provides employees with the proper tools and knowledge to immediately begin cleaning up a spill.
 - Ensure that employees are familiar with the site's spill control plan and/or proper spill cleanup procedures.
 - BMP IC17 discusses Spill Prevention and Control in detail.
- 3. Establish a regular training schedule, train all new employees, and conduct annual refresher training.**
- 4. Use a training log or similar method to document training.**

OPTIONAL:

- 9. Switch to non-toxic chemicals for maintenance when possible.**
 - If cleaning agents are used, select biodegradable products whenever feasible
 - Consider using a waterless and non-toxic chemical cleaning method for graffiti removal (e.g. gels or spray compounds).
- 10. Use chemicals that can be recycled.**
 - Buy recycled products to the maximum extent practicable

References

California Storm Water Best Management Practice Handbooks. Industrial/Commercial Best Management Practice Handbook. Prepared by Camp Dresser & McKee, Larry Walker Associates, Uribe and Associates, Resources Planning Associates for Stormwater Quality Task Force. March 1993.

King County Stormwater Pollution Control Manual. Best Management Practices for Businesses. King County Surface Water Management. July 1995. On-line: <http://dnr.metrokc.gov/wlr/dss/spcm.htm>

Stormwater Management Manual for Western Washington. Volume IV Source Control BMPs. Prepared by Washington State Department of Ecology Water Quality Program. Publication No. 99-14. August 2001.

INF-7: Underground Infiltration

Underground infiltration is a vault or chamber with an open bottom that used to store runoff and percolate into the subsurface. A number of vendors offer proprietary infiltration products that allow for similar or enhanced rates of infiltration and subsurface storage while offering durable prefrabricated structures. There are many varieties of proprietary infiltration BMPs that can be used for roads and parking lots, parks and open spaces, single and multi-family residential, or mixed-use and commercial uses.



Also known as:

- *Infiltration vault*
- *Recharge vault*

Underground Infiltration

Source: <http://www.contech-cpi.com>

Feasibility Screening Considerations

- Infiltration bays shall pass infeasible screening criteria to be considered for use.
- Underground infiltration galleries pose a potential risk of groundwater contamination; pretreatment should be used.

Opportunity Criteria

- Soils are adequate for infiltration or can be amended to provide an adequate infiltration rate.
- Appropriate for sites with limited surface space.
- Can be placed beneath roads, parking lots, parks, and athletic fields.
- Potential for groundwater contamination can be mitigated through isolation of pollutant sources, pretreatment of inflow, and/or demonstration of adequate treatment capacity of underlying soils.
- Infiltration is into native soil, or depth of engineered fill is ≤ 5 feet from the bottom of the facility to native material and infiltration into fill is approved by a geotechnical professional.
- Tributary area land uses include mixed-use and commercial, single-family and multi-family, roads and parking lots, and parks and open spaces. High pollutant land uses should not be tributary to infiltration BMPs.

OC-Specific Design Criteria and Considerations

- Placement of BMPs should observe geotechnical recommendations with respect to geological hazards (e.g. landslides, liquefaction zones, erosion, etc.) and set-backs (e.g., foundations, utilities, roadways, etc.)
- Minimum separation to mounded seasonally high groundwater of 10 feet shall be observed.
- Minimum pretreatment should be provided upstream of the infiltration facility, and water bypassing pretreatment should not be directed to the facility.
- Underground infiltration should not be used for drainage areas with high sediment production potential unless preceded by full treatment control with a BMP effective for sediment removal.
- Design infiltration rate should be determined as described in [Appendix VII](#).
- Inspection ports or similar design features shall be provided to verify continued system performance and identify need for major maintenance.

- For infiltration facilities beneath roads and parking areas, structural requirements should meet H-20 load requirements.

Computing Underground Infiltration Device Size

Underground infiltration devices vary by design and by proprietary designs. The sizing method selected for use must be based on the BMP type it most strongly resembles.

- For underground infiltration devices with open pore volume (e.g., vaults, crates, pipe sections, etc), sizing will be most similar to infiltration basins.
- For underground infiltration devices with pore space (e.g., aggregate reservoirs), sizing will be most similar to permeable pavement.

Additional References for Design Guidance

- Los Angeles Unified School District (LAUSD) Stormwater Technical Manual, Chapter 5:
http://www.laschools.org/employee/design/fs-studies-and-reports/download/white_paper_report_material/Storm_Water_Technical_Manual_2009-opt-red.pdf?version_id=76975850

IC15. PARKING AND STORAGE AREA MAINTENANCE

Pollution Prevention

Consider pollution prevention measures at all times for improving pollution control. Implementation of pollution prevention measures may reduce or eliminate the need to implement other more costly or complicated procedures.

The following pollution prevention principles apply to most industries:

- Affirmative Procurement - Use alternative, safer, or recycled products.
- Redirect storm water flows away from areas of concern.
- Reduce use of water or use dry methods.
- Reduce storm water flow across facility site.
- Recycle and reuse waste products and waste flows.
- Move or cover potential pollution from storm water contact.
- Provide on-going employee training in pollution prevention.

1. Conduct regular cleaning.
2. Properly collect and dispose of wash water.
3. Consider use of source treatment BMPs to treat runoff.
4. Keep the parking and storage areas clean and orderly.
5. When cleaning heavy oily deposits:
6. When conducting surface repair work:
7. Conduct inspections on a regular basis.
8. Keep accurate maintenance logs to evaluate materials removed/stored and improvements made.
9. Arrange rooftop drains to prevent drainage directly onto paved surfaces.
10. Train employees on these BMPs, storm water discharge prohibitions, and wastewater discharge requirements.

Best Management Practices

1. Conduct regular cleaning.

- Sweeping or vacuuming the parking facility is encouraged over other methods.
- Sweep all parking lots at least once before the onset of the wet season.

OPTIONAL:

- Establish frequency of sweeping based on usage and field observations of waste accumulation.

2. Properly collect and dispose of wash water.

- Block the storm drain or contain runoff.
- Wash water should be collected and pumped to the sanitary sewer or discharged to a pervious surface, do not allow wash water to enter storm drains. **DO NOT** discharge wash water to sanitary sewer until contacting the local sewer authority to find out if pretreatment is required.
- Dispose of parking lot sweeping debris and dirt at a landfill.

3. Consider use of source treatment BMPs to treat runoff.

- Allow sheet runoff to flow into biofilters (vegetated strip and swale) and/or infiltration devices.
- Utilize sand filters or oleophilic collectors for oily waste in low quantities.

4. Keep the parking and storage areas clean and orderly.

- Clean out and cover litter receptacles frequently to prevent spillage.
- Remove debris in a timely fashion.

OPTIONAL:

- Post "No Littering" signs.

5. When cleaning heavy oily deposits:

- If possible, clean oily spots with absorbent materials.
- Do not allow discharges to the storm drain.
- Appropriately dispose of spilled materials and absorbents.

6. When conducting surface repair work:

- Pre-heat, transfer or load hot bituminous material away from storm drain inlets.

- Conduct surface repair work during dry weather to prevent contamination from contacting stormwater runoff.
 - Cover and seal nearby storm drain inlets (with waterproof material or mesh) and manholes before applying seal coat, slurry seal, etc. Leave covers in place until job is complete and clean any debris for proper disposal.
 - To avoid runoff, use only as much water as necessary for dust control.
 - Use drip pans or absorbent material to catch drips from paving equipment that is not in use. Dispose of collected material and absorbents properly.
7. **Conduct inspections on a regular basis.**
 - Designate personnel to conduct inspections of the parking facilities and stormwater conveyance systems associated with them.
 - Inspect cleaning equipment/sweepers for leaks on a regular basis.
 8. **Keep accurate maintenance logs to evaluate materials removed/stored and improvements made.**
 9. **Arrange rooftop drains to prevent drainage directly onto paved surfaces.**

10. Training

1. **Train employees on these BMPs, storm water discharge prohibitions, and wastewater discharge requirements.**
2. **Train employees on proper spill containment and cleanup.**
 - Establish training that provides employees with the proper tools and knowledge to immediately begin cleaning up a spill.
 - Ensure that employees are familiar with the site's spill control plan and/or proper spill cleanup procedures.
 - BMP IC17 discusses Spill Prevention and Control in detail.
3. **Provide regular training to field employees and/or contractors regarding cleaning of paved areas and proper operation of equipment.**
4. **Establish a regular training schedule, train all new employees, and conduct annual refresher training.**
5. **Use a training log or similar method to document training.**

References

California Storm Water Best Management Practice Handbooks. Industrial/Commercial Best Management Practice Handbook. Prepared by Camp Dresser & McKee, Larry Walker Associates, Uribe and Associates, Resources Planning Associates for Stormwater Quality Task Force. March 1993.

King County Stormwater Pollution Control Manual. Best Management Practices for Businesses. King County Surface Water Management. July 1995. On-line: <http://dnr.metrokc.gov/wlr/dss/spcm.htm>

Model Urban Runoff Program: A How-To Guide for Developing Urban Runoff Programs for Small Municipalities. Prepared by City of Monterey, City of Santa Cruz, California Coastal Commission, Monterey Bay National Marine Sanctuary, Association of Monterey Bay Area Governments, Woodward-Clyde, Central Coast Regional Water Quality Control Board. July 1998 (Revised February 2002 by the California Coastal Commission).

Stormwater Management Manual for Western Washington. Volume IV Source Control BMPs. Prepared by Washington State Department of Ecology Water Quality Program. Publication No. 99-14. August 2001.

IC21. WASTE HANDLING AND DISPOSAL

Pollution Prevention

Consider pollution prevention measures at all times for improving pollution control. Implementation of pollution prevention measures may reduce or eliminate the need to implement other more costly or complicated procedures.

The following pollution prevention principles apply to most industries:

- Affirmative Procurement - Use alternative, safer, or recycled products.
- Redirect storm water flows away from areas of concern.
- Reduce use of water or use dry methods.
- Reduce storm water flow across facility site.
- Recycle and reuse waste products and waste flows.
- Move or cover potential pollution from storm water contact.
- Provide on-going employee training in pollution prevention.

1. Prevent waste materials from coming in direct contact with wind or rain.
 2. Design waste handling and disposal area to prevent stormwater runoff.
 3. Design waste handling and disposal area to contain spills.
 4. Keep waste collection areas clean.
 5. Secure solid waste containers when not in use.
 6. Regularly inspect, repair, and/or replace waste containers.
 7. Do not fill waste containers with washout water or any other liquid.
 8. Use all of a product before disposing of the container.
 9. Segregate wastes by type and label and date wastes.
 10. Label and store hazardous wastes according to hazardous waste regulations.
 11. Train employees on these BMPs, storm water discharge prohibitions, and wastewater discharge requirements.
- OPTIONAL:
12. Minimize waste.

Best Management Practices

1. **Prevent waste materials from coming in direct contact with wind or rain.**
 - Cover the waste management area with a permanent roof.
 - If this is not feasible, cover waste piles with temporary covering material such as reinforced tarpaulin, polyethylene, polyurethane, polypropylene, or hypalon.
 - Cover dumpsters to prevent rain from washing out waste materials.
2. **Design waste handling and disposal area to prevent stormwater runoff.**
 - Enclose the waste handling and disposal area or build a berm around it.
 - Position roof downspouts to direct stormwater away from waste handling and disposal area.
3. **Design waste handling and disposal area to contain spills.**
 - Place dumpsters or other waste receptacles on an impervious surface.
 - Construct a berm around the area to contain spills.
 - Install drains connected to the public sewer or the facility's process wastewater system within these contained areas. **DO NOT** discharge to a public sewer until contacting the local sewer authority to find out if pretreatment is required.
4. **Keep waste collection areas clean.**
 - When cleaning around waste handling and disposal areas use dry methods when possible (e.g. sweeping, use of absorbents).
 - If water must be used, collect water and discharge to the sewer if permitted to do so. **DO NOT** discharge to a public sewer until contacting the local sewer authority to find out if pretreatment is required. If discharge to the sanitary sewer is not allowed, pump water to a tank and dispose of properly.

OPTIONAL:

- Post “No Littering” signs.
5. **Secure solid waste containers when not in use.**
 6. **Regularly inspect, repair, and/or replace waste containers.**
 7. **Do not fill waste containers with washout water or any other liquid.**
 8. **Use all of a product before disposing of the container.**
 9. **Segregate wastes by type and label and date wastes.**
 - Do not mix wastes; this can cause chemical reactions, make recycling impossible, and complicate disposal.
 - Ensure that only appropriate solid wastes are added to solid waste containers.
 - Certain wastes such as hazardous wastes, appliances, fluorescent lamps, pesticides, etc. may not be disposed of in solid waste containers.
 10. **Label and store hazardous wastes according to hazardous waste regulations.**
 - Consult your local hazardous waste agency or Fire Department for details.
 - Obtain a hazardous waste generator license or permit.

11. Training

1. **Train employees on these BMPs, storm water discharge prohibitions, and wastewater discharge requirements.**
2. **Train employees in proper waste handling and disposal.**
3. **Train employees on proper spill containment and cleanup.**
 - Establish training that provides employees with the proper tools and knowledge to immediately begin cleaning up a spill.
 - Ensure that employees are familiar with the site’s spill control plan and/or proper spill cleanup procedures.
 - BMP IC17 discusses Spill Prevention and Control in detail.
4. **Establish a regular training schedule, train all new employees, and conduct annual refresher training.**
5. **Use a training log or similar method to document training.**

OPTIONAL:

12. Minimize waste.

- Recycle materials whenever possible.
- Modify processes or equipment to increase efficiency.
- Identify and promote use of non-hazardous alternatives.
- Reduction in the amount of waste generated can be accomplished using many different types of source controls such as:
 - Production planning and sequencing
 - Process or equipment modification
 - Raw material substitution or elimination
 - Loss prevention and housekeeping
 - Waste segregation and separation

- Close loop recycling
- Establish a material tracking system to increase awareness about material usage. This may reduce spills and minimize contamination, thus reducing the amount of waste produced.

References

California Storm Water Best Management Practice Handbooks. Industrial/Commercial Best Management Practice Handbook. Prepared by Camp Dresser & McKee, Larry Walker Associates, Uribe and Associates, Resources Planning Associates for Stormwater Quality Task Force. March 1993.

Model Urban Runoff Program: A How-To Guide for Developing Urban Runoff Programs for Small Municipalities. Prepared by City of Monterey, City of Santa Cruz, California Coastal Commission, Monterey Bay National Marine Sanctuary, Association of Monterey Bay Area Governments, Woodward-Clyde, Central Coast Regional Water Quality Control Board. July 1998 (Revised February 2002 by the California Coastal Commission).

OPTIONAL:

- ♦ Reduction in the amount of waste generated can be accomplished using many different types of source controls such as:
 - Production planning and sequencing
 - Process or equipment modification
 - Raw material substitution or elimination
 - Loss prevention and housekeeping
 - Waste segregation and separation
 - Close loop recycling

Establish a material tracking system to increase awareness about material usage. This may reduce spills and minimize contamination, thus reducing the amount of waste produced.



Clean beaches and healthy creeks, rivers, bays and ocean are important to Orange County. However, if we are not careful, our daily activities can lead directly to water pollution problems. Water that drains through your watershed can pick up pollutants which are then transported to our waterways and beautiful ocean.

You can prevent water pollution by taking personal action and by working with members of your watershed community to prevent urban runoff from entering your waterway.

For more information, please call the **Orange County Stormwater Program** at **1.877.89.SPILL** or visit www.ocwatersheds.com

To report a spill, call the **Orange County 24-Hour Water Pollution Problem Reporting Hotline** at **1.877.89.SPILL**.


For emergencies, dial 911.

The tips contained in this brochure provide useful information to help protect your watershed. If you have other suggestions, please contact your city's stormwater representatives or call the Orange County Stormwater Program.



Printed on Recycled Paper

Help Prevent Ocean Pollution: Tips For Protecting Your Watershed



The Ocean Begins
at Your Front Door



Tips for Protecting Your Watershed

My Watershed. Our Ocean.

Water + shed, noun: A region of land within which water flows down into a specified water body, such as a river, lake, sea, or ocean; a drainage basin or catchment basin.

Orange County is comprised of 11 major watersheds into which most of our water flows, connecting all of Orange County to the Pacific Ocean.



As water from rain (stormwater) or sprinklers and hoses (urban runoff) runs down your driveway and into your neighborhood streets, sidewalks

and gutters, it flows into storm drains that lead to waterways within your watershed. The waterways from other cities merge as they make their way through our watersheds until all the runoff water in Orange County meets at the Pacific Ocean. The water that reaches our ocean is not pure. As it flows through the watershed, it picks up pollutants such as litter, cigarette butts, fertilizer, pesticides, pet waste, motor oil and lawn clippings. Unlike water that enters the sewer (from sinks and toilets), water that enters the storm drain is not treated before it flows, ultimately, to the ocean.

Water quality can be improved by “Adopting Your Watershed.” Through this effort, we are challenging citizens and



organizations to join the Orange County Stormwater Program and others who are working to protect and restore our creeks, rivers, bays and ocean.

There are many opportunities to get involved:

- Appreciate your watershed - explore the creeks, trails and ocean and make observations about its conditions. If you see anything abnormal (such as dead fish, oil spills, leaking barrels, and other pollution) contact the Orange County 24-hour water pollution problem reporting hotline at 1.877.89.SPILL to report the problem.
- Research your watershed. Learn about what watershed you live in by visiting www.ocwatersheds.com.
- Find a watershed organization in your community and volunteer to help. If there are no active groups, consider starting your own.
- Visit EPA’s Adopt Your Watershed’s Catalog of Watershed Groups at www.epa.gov/adopt to locate groups in your community.
- Organize or join in a creek, river, bay or ocean cleanup event such as Coastal & Inner Coastal Cleanup Day that takes place the 3rd Saturday of every September. For more information visit www.coast4u.org.

Follow these simple tips to protect the water quality of your watershed:

- Sweep up debris and dispose of it in the trash. Do not hose down driveways or sidewalks into the street or gutter.
- Use dry cleanup methods such as cat litter to absorb spills and sweep up residue.
- Set your irrigation systems to reflect seasonal water needs or use weather-based controllers. Inspect for runoff regularly.
- Cover trashcans securely.
- Take hazardous waste to a household hazardous waste collection center. (For example, paint, batteries and petroleum products)
- Pick up after your pet.
- Follow application and disposal directions for pesticides and fertilizers.
- If you wash your car at home, wash it on your lawn or divert the runoff onto a landscaped area. Consider taking your car to a commercial car wash, where the water is reclaimed or recycled.
 - Keep your car well maintained.
 - Never pour oil or antifreeze in the street, gutter or storm drain.





Preventing water pollution at your commercial/industrial site

Clean beaches and healthy creeks, rivers, bays and ocean are important to Orange County. However, many landscape and building maintenance activities can lead to water pollution if you're not careful. Paint, chemicals, plant clippings and other materials can be blown or washed into storm drains that flow to the ocean. Unlike water in sanitary sewers (from sinks and toilets), water in storm drains is not treated before entering our waterways.

You would never pour soap or fertilizers into the ocean, so why would you let them enter the storm drains? Follow these easy tips to help prevent water pollution.

Some types of industrial facilities are required to obtain coverage under the State General Industrial Permit. For more information visit: www.swrcb.ca.gov/stormwater/industrial.html

For more information,
please call the
Orange County Stormwater Program
at **1-877-89-SPILL** (1-877-897-7455)
or visit
www.ocwatersheds.com

To report a spill,
call the
**Orange County 24-Hour
Water Pollution Problem
Reporting Hotline**
at **1-877-89-SPILL** (1-877-897-7455).

For emergencies, dial 911.



RECYCLE
USED OIL



Printed on Recycled Paper

Help Prevent Ocean Pollution:

Proper Maintenance Practices for Your Business



**The Ocean Begins
at Your Front Door**



Proper Maintenance Practices for your Business

Landscape Maintenance

- Compost grass clippings, leaves, sticks and other vegetation, or dispose of it at a permitted landfill or in green waste containers. Do not dispose of these materials in the street, gutter or storm drain.
- Irrigate slowly and inspect the system for leaks, overspraying and runoff. Adjust automatic timers to avoid overwatering.
- Follow label directions for the use and disposal of fertilizers and pesticides.
- Do not apply pesticides or fertilizers if rain is expected within 48 hours or if wind speeds are above 5 mph.
- Do not spray pesticides within 100 feet of waterways.
- Fertilizers should be worked into the soil rather than dumped onto the surface.
- If fertilizer is spilled on the pavement or sidewalk, sweep it up immediately and place it back in the container.

Building Maintenance

- Never allow washwater, sweepings or sediment to enter the storm drain.
- Sweep up dry spills and use cat litter, towels or similar materials to absorb wet spills. Dispose of it in the trash.
- If you wash your building, sidewalk or parking lot, you **must** contain the water. Use a shop vac to collect the water and contact your city or sanitation agency for proper disposal information. Do not let water enter the street, gutter or storm drain.
- Use drop cloths underneath outdoor painting, scraping, and sandblasting work, and properly dispose of materials in the trash.
- Use a ground cloth or oversized tub for mixing paint and cleaning tools.
- Use a damp mop or broom to clean floors.
- Cover dumpsters to keep insects, animals, rainwater and sand from entering. Keep the area around the dumpster clear of trash and debris. Do not overfill the dumpster.

- Call your trash hauler to replace leaking dumpsters.
- Do not dump any toxic substance or liquid waste on the pavement, the ground, or near a storm drain. Even materials that seem harmless such as latex paint or biodegradable cleaners can damage the environment.
- Recycle paints, solvents and other materials. For more information about recycling and collection centers, visit www.oclandfills.com.
- Store materials indoors or under cover and away from storm drains.
- Use a construction and demolition recycling company to recycle lumber, paper, cardboard, metals, masonry, carpet, plastic, pipes, drywall, rocks, dirt, and green waste. For a listing of construction and demolition recycling locations in your area, visit www.ciwmb.ca.gov/recycle.
- Properly label materials. Familiarize employees with Material Safety Data Sheets.

NEVER DISPOSE
OF ANYTHING
IN THE STORM
DRAIN.



Clean beaches and healthy creeks, rivers, bays and ocean are important to Orange County. However, many common activities can lead to water pollution if you're not careful. Fertilizers, pesticides and other chemicals that are left on yards or driveways can be blown or washed into storm drains that flow to the ocean. Overwatering lawns can also send materials into storm drains. Unlike water in sanitary sewers (from sinks and toilets), water in storm drains is not treated before entering our waterways.

You would never pour gardening products into the ocean, so don't let them enter the storm drains. Follow these easy tips to help prevent water pollution.

For more information, please call the **Orange County Stormwater Program** at **1-877-89-SPILL** (1-877-897-7455) or visit www.ocwatersheds.com

UCCE Master Gardener Hotline:
(714) 708-1646

To report a spill, call the **Orange County 24-Hour Water Pollution Problem Reporting Hotline** **1-877-89-SPILL** (1-877-897-7455).

For emergencies, dial 911.


The tips contained in this brochure provide useful information to help prevent water pollution while landscaping or gardening. If you have other suggestions, please contact your city's stormwater representatives or call the Orange County Stormwater Program.



Printed on Recycled Paper

Help Prevent Ocean Pollution:

Tips for Landscape & Gardening



The Ocean Begins
at Your Front Door



Tips for Landscape & Gardening

Never allow gardening products or polluted water to enter the street, gutter or storm drain.

General Landscaping Tips

- Protect stockpiles and materials from wind and rain by storing them under tarps or secured plastic sheeting.
- Prevent erosion of slopes by planting fast-growing, dense ground covering plants. These will shield and bind the soil.
- Plant native vegetation to reduce the amount of water, fertilizers, and pesticide applied to the landscape.
- Never apply pesticides or fertilizers when rain is predicted within the next 48 hours.



Garden & Lawn Maintenance

- Do not overwater. Use irrigation practices such as drip irrigation, soaker hoses or micro spray systems. Periodically inspect and fix leaks and misdirected sprinklers.

- Do not rake or blow leaves, clippings or pruning waste into the street, gutter or storm drain. Instead, dispose of green waste by composting, hauling it to a permitted landfill, or recycling it through your city's program.



- Use slow-release fertilizers to minimize leaching, and use organic fertilizers.
- Read labels and use only as directed. Do not over-apply pesticides or fertilizers. Apply to spots as needed, rather than blanketing an entire area.
- Store pesticides, fertilizers and other chemicals in a dry covered area to prevent exposure that may result in the deterioration of containers and packaging.
- Rinse empty pesticide containers and re-use rinse water as you would use the



product. Do not dump rinse water down storm drains. Dispose of empty containers in the trash.

- When available, use non-toxic alternatives to traditional pesticides, and use pesticides specifically designed to control the pest you are targeting. For more information, visit www.ipm.ucdavis.edu.
- If fertilizer is spilled, sweep up the spill before irrigating. If the spill is liquid, apply an absorbent material such as cat litter, and then sweep it up and dispose of it in the trash.
- Take unwanted pesticides to a Household Hazardous Waste Collection Center to be recycled. Locations are provided below.

Household Hazardous Waste Collection Centers

Anaheim:	1071 N. Blue Gum St.
Huntington Beach:	17121 Nichols St.
Irvine:	6411 Oak Canyon
San Juan Capistrano:	32250 La Pata Ave.

For more information, call (714) 834-6752 or visit www.oilandfills.com



Support from Orange County residents and businesses is needed to improve water quality and reduce urban runoff pollution. Proper use and disposal of materials will help stop pollution before it reaches the storm drain and the ocean.

Stormwater quality management programs have been developed throughout Orange County to educate and encourage the public to protect water quality, monitor runoff in the storm drain system, investigate illegal dumping and maintain storm drains.

Non-point source pollution can have a serious impact on water quality in Orange County. Pollutants from the storm drain system can harm marine life as well as coastal and wetland habitats. They can also degrade recreation areas such as beaches, harbors and bays.



The Effect on the Ocean



- Automotive leaks and spills.
- Improper disposal of used oil and other engine fluids.
- Metals found in vehicle exhaust, weathered paint, rust, metal plating and tires.
- Pesticides and fertilizers from lawns, gardens and farms.
- Improper disposal of cleaners, paint and paint removers.
- Soil erosion and dust debris from landscape and construction activities.
- Litter, lawn clippings, animal waste, and other organic matter.
- Oil stains on parking lots and paved surfaces.

Sources of Non-Point Source Pollution

- Anything we use outside homes, vehicles and businesses – like motor oil, paint, pesticides, fertilizers and cleaners – can be blown or washed into storm drains.
- A little water from a garden hose or rain can also send materials into storm drains.
- Storm drains are separate from our sanitary sewer systems; unlike water in sanitary sewers (from sinks or toilets), water in storm drains is not treated before entering our waterways.

Where Does It Go?

- Most people believe that the largest source of water pollution in urban areas comes from specific sources such as factories and sewage treatment plants. In fact, the largest source of water pollution comes from city streets, neighborhoods, construction sites and parking lots. This type of pollution is sometimes called “non-point source” pollution.
- There are two types of non-point source pollution: stormwater and urban runoff.
- Stormwater runoff results from rainfall.
- When rainstorms cause large volumes of water to rinse the urban landscape, picking up pollutants along the way.
- Urban runoff can happen any time of the year when excessive water use from irrigation, vehicle washing and other sources carries trash, lawn clippings and other urban pollutants into storm drains.

Did You Know?

Even if you live miles from the Pacific Ocean, you may be unknowingly polluting it.

Dumping one quart of motor oil into a storm drain can contaminate 250,000 gallons of water.

For More Information

California Environmental Protection Agency

www.calepa.ca.gov

- **Air Resources Board**
www.arb.ca.gov
- **Department of Pesticide Regulation**
www.cdpr.ca.gov
- **Department of Toxic Substances Control**
www.dtsc.ca.gov
- **Integrated Waste Management Board**
www.ciwmb.ca.gov
- **Office of Environmental Health Hazard Assessment**
www.oehha.ca.gov
- **State Water Resources Control Board**
www.waterboards.ca.gov

Earth 911 - Community-Specific Environmental Information 1-800-cleanup or visit www.1800cleanup.org

Health Care Agency's Ocean and Bay Water Closure and Posting Hotline
(714) 433-6400 or visit www.ocbeachinfo.com

Integrated Waste Management Dept. of Orange County (714) 834-6752 or visit www.oclandfills.com for information on household hazardous waste collection centers, recycling centers and solid waste collection

O.C. Agriculture Commissioner
(714) 447-7100 or visit www.ocagcomm.com

Stormwater Best Management Practice Handbook
Visit www.cabmphandbooks.com

UC Master Gardener Hotline
(714) 708-1646 or visit www.ucemg.com

The Orange County Stormwater Program has created and moderates an electronic mailing list to facilitate communications, take questions and exchange ideas among its users about issues and topics related to stormwater and urban runoff and the implementation of program elements. To join the list, please send an email to ocstormwaterinfo-join@list.ocwatersheds.com

Orange County Stormwater Program

Aliso Viejo	(949)	425-2535
Anaheim Public Works Operations	(714)	765-6860
Brea Engineering	(714)	990-7666
Buena Park Public Works	(714)	562-3655
Costa Mesa Public Services	(714)	754-5323
Cypress Public Works	(714)	229-6740
Dana Point Public Works	(949)	248-3584
Fountain Valley Public Works	(714)	593-4441
Fullerton Engineering Dept.	(714)	738-6853
Garden Grove Public Works	(714)	741-5956
Huntington Beach Public Works	(714)	536-5431
Irvine Public Works	(949)	724-6315
La Habra Public Services	(562)	905-9792
La Palma Public Works	(714)	690-3310
Laguna Beach Water Quality	(949)	497-0378
Laguna Hills Public Services	(949)	707-2650
Laguna Niguel Public Works	(949)	362-4337
Laguna Woods Public Works	(949)	639-0500
Lake Forest Public Works	(949)	461-3480
Los Alamitos Community Dev.	(562)	431-3538
Mission Viejo Public Works	(949)	470-3056
Newport Beach, Code & Water Quality Enforcement	(949)	644-3215
Orange Public Works	(714)	532-6480
Placentia Public Works	(714)	993-8245
Rancho Santa Margarita	(949)	635-1800
San Clemente Environmental Programs	(949)	361-6143
San Juan Capistrano Engineering	(949)	234-4413
Santa Ana Public Works	(714)	647-3380
Seal Beach Engineering	(562)	431-2527 x317
Stanton Public Works	(714)	379-9222 x204
Tustin Public Works/Engineering	(714)	573-3150
Villa Park Engineering	(714)	998-1500
Westminster Public Works/Engineering	(714)	898-3311 x446
Yorba Linda Engineering	(714)	961-7138
Orange County Stormwater Program	(877)	897-7455
Orange County 24-Hour Water Pollution Problem Reporting Hotline 1-877-89-SPILL (1-877-897-7455)		

On-line Water Pollution Problem Reporting Form
www.ocwatersheds.com



The Ocean Begins at Your Front Door



Never allow pollutants to enter the street, gutter or storm drain!

Follow these simple steps to help reduce water pollution:

Household Activities

- Do not rinse spills with water. Use dry cleanup methods such as applying cat litter or another absorbent material, sweep and dispose of in the trash. Take items such as used or excess batteries, oven cleaners, automotive fluids, painting products and cathode ray tubes, like TVs and computer monitors, to a Household Hazardous Waste Collection Center (HHWCC).
- For a HHWCC near you call (714) 834-6752 or visit www.oilandfills.com.
- Do not hose down your driveway, sidewalk or patio to the street, gutter or storm drain. Sweep up debris and dispose of it in the trash.

Automotive

- Take your vehicle to a commercial car wash whenever possible. If you wash your vehicle at home, choose soaps, cleaners, or detergents labeled non-toxic, phosphate-free or biodegradable. Vegetable and citrus-based products are typically safest for the environment.
- Do not allow washwater from vehicle washing to drain into the street, gutter or storm drain. Excess washwater should be disposed of in the sanitary sewer (through a sink or toilet) or onto an absorbent surface like your lawn.
- Monitor your vehicles for leaks and place a pan under leaks. Keep your vehicles well maintained to stop and prevent leaks.
- Never pour oil or antifreeze in the street, gutter or storm drain. Recycle these substances at a service station, a waste oil collection center or used oil recycling center. For the nearest Used Oil Collection Center call 1-800-CLEANUP or visit www.1800cleanup.org.

Pool Maintenance

- Pool and spa water must be dechlorinated and free of excess acid, alkali or color to be allowed in the street, gutter or storm drain.
- When it is not raining, drain dechlorinated pool and spa water directly into the sanitary sewer.
- Some cities may have ordinances that do not allow pool water to be disposed of in the storm drain. Check with your city.

Landscape and Gardening

- Do not over-water. Water your lawn and garden by hand to control the amount of water you use or set irrigation systems to reflect seasonal water needs. If water flows off your yard onto your driveway or sidewalk, your system is over-watering. Periodically inspect and fix leaks and misdirected sprinklers.
- Do not rake or blow leaves, clippings or pruning waste into the street, gutter or storm drain. Instead, dispose of waste by composting, hauling it to a permitted landfill, or as green waste through your city's recycling program.
- Follow directions on pesticides and fertilizer, (measure, do not estimate amounts) and do not use if rain is predicted within 48 hours.
- Take unwanted pesticides to a HHWCC to be recycled. For locations and hours of HHWCC, call (714) 834-6752 or visit www.oilandfills.com.

Trash

- Place trash and litter that cannot be recycled in securely covered trash cans.
- Whenever possible, buy recycled products.
- Remember: Reduce, Reuse, Recycle.

Pet Care

- Always pick up after your pet. Flush waste down the toilet or dispose of it in the trash. Pet waste, if left outdoors, can wash into the street, gutter or storm drain.
- If possible, bathe your pets indoors. If you must bathe your pet outside, wash it on your lawn or another absorbent/permeable surface to keep the washwater from entering the street, gutter or storm drain.
- Follow directions for use of pet care products and dispose of any unused products at a HHWCC.

Common Pollutants

Home Maintenance

- Detergents, cleaners and solvents
- Oil and latex paint
- Swimming pool chemicals
- Outdoor trash and litter


Lawn and Garden

- Pet and animal waste
- Pesticides
- Clippings, leaves and soil
- Fertilizer

Automobile

- Oil and grease
- Radiator fluids and antifreeze
- Cleaning chemicals
- Brake pad dust

Attachment E



DRAINAGE AREA 1
TOTAL DRAINAGE AREA = 0.33
IMPERVIOUS = 0.84

DRAINAGE AREA 6
TOTAL DRAINAGE AREA = 0.16
IMPERVIOUS AREA = 0.85

DRAINAGE AREA 5
TOTAL DRAINAGE AREA = 0.41
IMPERVIOUS AREA = 0.51

DRAINAGE AREA 3
TOTAL DRAINAGE AREA = 0.34
IMPERVIOUS = 0.73

DRAINAGE AREA 2
TOTAL DRAINAGE AREA = 0.19
IMPERVIOUS = 0.75

DRAINAGE AREA 8
TOTAL DRAINAGE AREA = 0.12
IMPERVIOUS AREA = 0.74

DRAINAGE AREA 4
TOTAL DRAINAGE AREA = 0.32
IMPERVIOUS AREA = 0.92

DRAINAGE AREA 9
TOTAL DRAINAGE AREA = 1.44
IMPERVIOUS AREA = 0.29

DRAINAGE AREA 7
TOTAL DRAINAGE AREA = 0.26
IMPERVIOUS AREA = 1.00

LEGEND

- LIMIT OF WORK
- DRAINAGE AREA 1 - "DA1"
- DRAINAGE AREA 2 - "DA2"
- DRAINAGE AREA 3 - "DA3"
- DRAINAGE AREA 4 - "DA4"
- DRAINAGE AREA 5 - "DA5"
- DRAINAGE AREA 6 - "DA6"
- DRAINAGE AREA 7 - "DA7"
- DRAINAGE AREA 8 - "DA8"
- DRAINAGE AREA 9 - "DA9"
- DIRECTION OF FLOW



THE LIONS PARK PROJECTS

ARCHITECT
JOHNSON FAVARO
Architecture and Urban Design
5888 Blackwelder Street, Ground Floor
Culver City, CA 90232
(Tel) 310-559-5720 (Fax) 310-559-8220

CONSULTING ENGINEERS

kpff
6080 Center Dr., Suite 700
Los Angeles, CA 90045
O: 310.665.2800
F: 310.665.3075
www.kpff.com

The drawings and specifications, ideas, designs, and arrangements are and shall remain the property of the architect. No part thereof shall be copied or used in connection with any work or project other than the specific project for which they have been prepared without the written consent of the architect. Visual contact with these drawings or specifications shall constitute evidence of acceptance of these restrictions.
Written dimensions on these drawings shall have precedence over scaled dimensions. Contractor shall verify and be responsible for all dimensions and conditions on the job and this office must be notified of any variation from the dimensions and conditions shown by these drawings. Shop details must be submitted to the office for approval before processing with fabrication.
© Johnson Favaro 2015

ARCHITECT'S / ENGINEER'S STAMP



CITY APPROVALS

DRAFT - NOT FOR CONSTRUCTION

REVISION 01

No.	Issue	Date
90% CD SUBMITTAL		12/19/16
50% CD SUBMITTAL		11/10/16
100% DD SUBMITTAL		08/15/16
100% SD SUBMITTAL		04/19/16
Issue		
ISSUE / REVISIONS		

TITLE:

SCALE: As Noted DATE: November 10, 2016

DRAWN BY: LL CHECKED BY: GT

PROJECT #: 1500059

DRAINAGE AREA 1

TECHNICAL GUIDANCE DOCUMENT APPENDICES

Worksheet B: Simple Design Capture Volume Sizing Method

Step 1: Determine the design capture storm depth used for calculating volume				
1	Enter design capture storm depth from Figure III.1, d (inches)	$d=$	0.75	inches
2	Enter the effect of provided HSCs, d_{HSC} (inches) (Worksheet A)	$d_{HSC}=$	0.00	inches
3	Calculate the remainder of the design capture storm depth, $d_{remainder}$ (inches) (Line 1 - Line 2)	$d_{remainder}=$	0.75	inches
Step 2: Calculate the DCV				
1	Enter Project area tributary to BMP (s), A (acres)	$A=$	0.33	acres
2	Enter Project Imperviousness, imp (unitless)	$imp=$	0.84	
3	Calculate runoff coefficient, $C = (0.75 \times imp) + 0.15$	$C=$	0.78	
4	Calculate runoff volume, $V_{design} = (C \times d_{remainder} \times A \times 43560 \times (1/12))$	$V_{design}=$	700.8	cu-ft
Step 3: Design BMPs to ensure full retention of the DCV				
Step 3a: Determine design infiltration rate				
1	Enter measured infiltration rate, $K_{observed}^1$ (in/hr) (Appendix VII)	$K_{observed}=$	12	In/hr
2	Enter combined safety factor from Worksheet H, S_{total} (unitless)	$S_{total}=$	1.56	
3	Calculate design infiltration rate, $K_{design} = K_{observed} / S_{total}$	$K_{design}=$	7.68	In/hr
Step 3b: Determine minimum BMP footprint				
4	Enter drawdown time, T (max 48 hours)	$T=$	48	Hours
5	Calculate max retention depth that can be drawn down within the drawdown time (feet), $D_{max} = K_{design} \times T \times (1/12)$	$D_{max}=$	30	feet
6	Calculate minimum area required for BMP (sq-ft), $A_{min} = V_{design} / d_{max}$	$A_{min}=$	23.4	sq-ft

¹ $K_{observed}$ is the vertical infiltration measured in the field, before applying a factor of safety. If field testing measures a rate that is different than the vertical infiltration rate (for example, three-dimensional borehole percolation rate), then this rate must be adjusted by an acceptable method (for example, Porchet method) to yield the field estimate of vertical infiltration rate, $K_{observed}$. See Appendix VII.

Worksheet B: Simple Design Capture Volume Sizing Method

Step 1: Determine the design capture storm depth used for calculating volume				
1	Enter design capture storm depth from Figure III.1, d (inches)	$d=$	0.75	inches
2	Enter the effect of provided HSCs, d_{HSC} (inches) (Worksheet A)	$d_{HSC}=$	0.00	inches
3	Calculate the remainder of the design capture storm depth, $d_{remainder}$ (inches) (Line 1 - Line 2)	$d_{remainder}=$	0.75	inches
Step 2: Calculate the DCV				
1	Enter Project area tributary to BMP (s), A (acres)	$A=$	0.19	acres
2	Enter Project Imperviousness, imp (unitless)	$imp=$	0.75	
3	Calculate runoff coefficient, $C = (0.75 \times imp) + 0.15$	$C=$	0.71	
4	Calculate runoff volume, $V_{design} = (C \times d_{remainder} \times A \times 43560 \times (1/12))$	$V_{design}=$	367.3	cu-ft
Step 3: Design BMPs to ensure full retention of the DCV				
Step 3a: Determine design infiltration rate				
1	Enter measured infiltration rate, $K_{observed}^1$ (in/hr) (Appendix VII)	$K_{observed}=$	12	In/hr
2	Enter combined safety factor from Worksheet H, S_{total} (unitless)	$S_{total}=$	1.56	
3	Calculate design infiltration rate, $K_{design} = K_{observed} / S_{total}$	$K_{design}=$	7.68	In/hr
Step 3b: Determine minimum BMP footprint				
4	Enter drawdown time, T (max 48 hours)	$T=$	48	Hours
5	Calculate max retention depth that can be drawn down within the drawdown time (feet), $D_{max} = K_{design} \times T \times (1/12)$	$D_{max}=$	30	feet
6	Calculate minimum area required for BMP (sq-ft), $A_{min} = V_{design} / d_{max}$	$A_{min}=$	12.2	sq-ft

¹ $K_{observed}$ is the vertical infiltration measured in the field, before applying a factor of safety. If field testing measures a rate that is different than the vertical infiltration rate (for example, three-dimensional borehole percolation rate), then this rate must be adjusted by an acceptable method (for example, Porchet method) to yield the field estimate of vertical infiltration rate, $K_{observed}$. See Appendix VII.

Worksheet B: Simple Design Capture Volume Sizing Method

Step 1: Determine the design capture storm depth used for calculating volume				
1	Enter design capture storm depth from Figure III.1, d (inches)	$d=$	0.75	inches
2	Enter the effect of provided HSCs, d_{HSC} (inches) (Worksheet A)	$d_{HSC}=$	0.00	inches
3	Calculate the remainder of the design capture storm depth, $d_{remainder}$ (inches) (Line 1 - Line 2)	$d_{remainder}=$	0.75	inches
Step 2: Calculate the DCV				
1	Enter Project area tributary to BMP (s), A (acres)	$A=$	0.34	acres
2	Enter Project Imperviousness, imp (unitless)	$imp=$	0.73	
3	Calculate runoff coefficient, $C = (0.75 \times imp) + 0.15$	$C=$	0.70	
4	Calculate runoff volume, $V_{design} = (C \times d_{remainder} \times A \times 43560 \times (1/12))$	$V_{design}=$	648.0	cu-ft
Step 3: Design BMPs to ensure full retention of the DCV				
Step 3a: Determine design infiltration rate				
1	Enter measured infiltration rate, $K_{observed}^1$ (in/hr) (Appendix VII)	$K_{observed}=$	12	In/hr
2	Enter combined safety factor from Worksheet H, S_{total} (unitless)	$S_{total}=$	1.56	
3	Calculate design infiltration rate, $K_{design} = K_{observed} / S_{total}$	$K_{design}=$	7.68	In/hr
Step 3b: Determine minimum BMP footprint				
4	Enter drawdown time, T (max 48 hours)	$T=$	48	Hours
5	Calculate max retention depth that can be drawn down within the drawdown time (feet), $D_{max} = K_{design} \times T \times (1/12)$	$D_{max}=$	30	feet
6	Calculate minimum area required for BMP (sq-ft), $A_{min} = V_{design} / d_{max}$	$A_{min}=$	21.6	sq-ft

¹ $K_{observed}$ is the vertical infiltration measured in the field, before applying a factor of safety. If field testing measures a rate that is different than the vertical infiltration rate (for example, three-dimensional borehole percolation rate), then this rate must be adjusted by an acceptable method (for example, Porchet method) to yield the field estimate of vertical infiltration rate, $K_{observed}$. See Appendix VII.

Worksheet B: Simple Design Capture Volume Sizing Method

Step 1: Determine the design capture storm depth used for calculating volume				
1	Enter design capture storm depth from Figure III.1, d (inches)	$d=$	0.75	inches
2	Enter the effect of provided HSCs, d_{HSC} (inches) (Worksheet A)	$d_{HSC}=$	0.00	inches
3	Calculate the remainder of the design capture storm depth, $d_{remainder}$ (inches) (Line 1 - Line 2)	$d_{remainder}=$	0.75	inches
Step 2: Calculate the DCV				
1	Enter Project area tributary to BMP (s), A (acres)	$A=$	0.32	acres
2	Enter Project Imperviousness, imp (unitless)	$imp=$	0.92	
3	Calculate runoff coefficient, $C = (0.75 \times imp) + 0.15$	$C=$	0.84	
4	Calculate runoff volume, $V_{design} = (C \times d_{remainder} \times A \times 43560 \times (1/12))$	$V_{design}=$	731.8	cu-ft
Step 3: Design BMPs to ensure full retention of the DCV				
Step 3a: Determine design infiltration rate				
1	Enter measured infiltration rate, $K_{observed}^1$ (in/hr) (Appendix VII)	$K_{observed}=$	12	In/hr
2	Enter combined safety factor from Worksheet H, S_{total} (unitless)	$S_{total}=$	1.56	
3	Calculate design infiltration rate, $K_{design} = K_{observed} / S_{total}$	$K_{design}=$	7.68	In/hr
Step 3b: Determine minimum BMP footprint				
4	Enter drawdown time, T (max 48 hours)	$T=$	48	Hours
5	Calculate max retention depth that can be drawn down within the drawdown time (feet), $D_{max} = K_{design} \times T \times (1/12)$	$D_{max}=$	30	feet
6	Calculate minimum area required for BMP (sq-ft), $A_{min} = V_{design} / d_{max}$	$A_{min}=$	24.4	sq-ft

¹ $K_{observed}$ is the vertical infiltration measured in the field, before applying a factor of safety. If field testing measures a rate that is different than the vertical infiltration rate (for example, three-dimensional borehole percolation rate), then this rate must be adjusted by an acceptable method (for example, Porchet method) to yield the field estimate of vertical infiltration rate, $K_{observed}$. See Appendix VII.

Worksheet B: Simple Design Capture Volume Sizing Method

Step 1: Determine the design capture storm depth used for calculating volume				
1	Enter design capture storm depth from Figure III.1, d (inches)	$d=$	0.75	inches
2	Enter the effect of provided HSCs, d_{HSC} (inches) (Worksheet A)	$d_{HSC}=$	0.00	inches
3	Calculate the remainder of the design capture storm depth, $d_{remainder}$ (inches) (Line 1 - Line 2)	$d_{remainder}=$	0.75	inches
Step 2: Calculate the DCV				
1	Enter Project area tributary to BMP (s), A (acres)	$A=$	0.41	acres
2	Enter Project Imperviousness, imp (unitless)	$imp=$	0.51	
3	Calculate runoff coefficient, $C= (0.75 \times imp) + 0.15$	$C=$	0.53	
4	Calculate runoff volume, $V_{design}= (C \times d_{remainder} \times A \times 43560 \times (1/12))$	$V_{design}=$	591.6	cu-ft
Step 3: Design BMPs to ensure full retention of the DCV				
Step 3a: Determine design infiltration rate				
1	Enter measured infiltration rate, $K_{observed}^1$ (in/hr) (Appendix VII)	$K_{observed}=$	12	In/hr
2	Enter combined safety factor from Worksheet H, S_{total} (unitless)	$S_{total}=$	1.56	
3	Calculate design infiltration rate, $K_{design} = K_{observed} / S_{total}$	$K_{design}=$	7.68	In/hr
Step 3b: Determine minimum BMP footprint				
4	Enter drawdown time, T (max 48 hours)	$T=$	48	Hours
5	Calculate max retention depth that can be drawn down within the drawdown time (feet), $D_{max} = K_{design} \times T \times (1/12)$	$D_{max}=$	30	feet
6	Calculate minimum area required for BMP (sq-ft), $A_{min} = V_{design} / d_{max}$	$A_{min}=$	19.7	sq-ft

¹ $K_{observed}$ is the vertical infiltration measured in the field, before applying a factor of safety. If field testing measures a rate that is different than the vertical infiltration rate (for example, three-dimensional borehole percolation rate), then this rate must be adjusted by an acceptable method (for example, Porchet method) to yield the field estimate of vertical infiltration rate, $K_{observed}$. See Appendix VII.

Worksheet B: Simple Design Capture Volume Sizing Method

Step 1: Determine the design capture storm depth used for calculating volume				
1	Enter design capture storm depth from Figure III.1, d (inches)	$d=$	0.75	inches
2	Enter the effect of provided HSCs, d_{HSC} (inches) (Worksheet A)	$d_{HSC}=$	0.00	inches
3	Calculate the remainder of the design capture storm depth, $d_{remainder}$ (inches) (Line 1 - Line 2)	$d_{remainder}=$	0.75	inches
Step 2: Calculate the DCV				
1	Enter Project area tributary to BMP (s), A (acres)	$A=$	0.16	acres
2	Enter Project Imperviousness, imp (unitless)	$imp=$	0.85	
3	Calculate runoff coefficient, $C = (0.75 \times imp) + 0.15$	$C=$	0.79	
4	Calculate runoff volume, $V_{design} = (C \times d_{remainder} \times A \times 43560 \times (1/12))$	$V_{design}=$	344.1	cu-ft
Step 3: Design BMPs to ensure full retention of the DCV				
Step 3a: Determine design infiltration rate				
1	Enter measured infiltration rate, $K_{observed}^1$ (in/hr) (Appendix VII)	$K_{observed}=$	12	In/hr
2	Enter combined safety factor from Worksheet H, S_{total} (unitless)	$S_{total}=$	1.56	
3	Calculate design infiltration rate, $K_{design} = K_{observed} / S_{total}$	$K_{design}=$	7.68	In/hr
Step 3b: Determine minimum BMP footprint				
4	Enter drawdown time, T (max 48 hours)	$T=$	48	Hours
5	Calculate max retention depth that can be drawn down within the drawdown time (feet), $D_{max} = K_{design} \times T \times (1/12)$	$D_{max}=$	30	feet
6	Calculate minimum area required for BMP (sq-ft), $A_{min} = V_{design} / d_{max}$	$A_{min}=$	11.5	sq-ft

¹ $K_{observed}$ is the vertical infiltration measured in the field, before applying a factor of safety. If field testing measures a rate that is different than the vertical infiltration rate (for example, three-dimensional borehole percolation rate), then this rate must be adjusted by an acceptable method (for example, Porchet method) to yield the field estimate of vertical infiltration rate, $K_{observed}$. See Appendix VII.

DRAINAGE AREA 7

TECHNICAL GUIDANCE DOCUMENT APPENDICES

Worksheet B: Simple Design Capture Volume Sizing Method

Step 1: Determine the design capture storm depth used for calculating volume				
1	Enter design capture storm depth from Figure III.1, d (inches)	$d=$	0.75	inches
2	Enter the effect of provided HSCs, d_{HSC} (inches) (Worksheet A)	$d_{HSC}=$	0.00	inches
3	Calculate the remainder of the design capture storm depth, $d_{remainder}$ (inches) (Line 1 - Line 2)	$d_{remainder}=$	0.75	inches
Step 2: Calculate the DCV				
1	Enter Project area tributary to BMP (s), A (acres)	$A=$	0.26	acres
2	Enter Project Imperviousness, imp (unitless)	$imp=$	1.00	
3	Calculate runoff coefficient, $C= (0.75 \times imp) + 0.15$	$C=$	0.90	
4	Calculate runoff volume, $V_{design}= (C \times d_{remainder} \times A \times 43560 \times (1/12))$	$V_{design}=$	637.1	cu-ft
Step 3: Design BMPs to ensure full retention of the DCV				
Step 3a: Determine design infiltration rate				
1	Enter measured infiltration rate, $K_{observed}^1$ (in/hr) (Appendix VII)	$K_{observed}=$	12	In/hr
2	Enter combined safety factor from Worksheet H, S_{total} (unitless)	$S_{total}=$	1.56	
3	Calculate design infiltration rate, $K_{design} = K_{observed} / S_{total}$	$K_{design}=$	7.68	In/hr
Step 3b: Determine minimum BMP footprint				
4	Enter drawdown time, T (max 48 hours)	$T=$	48	Hours
5	Calculate max retention depth that can be drawn down within the drawdown time (feet), $D_{max} = K_{design} \times T \times (1/12)$	$D_{max}=$	30	feet
6	Calculate minimum area required for BMP (sq-ft), $A_{min} = V_{design} / d_{max}$	$A_{min}=$	21.2	sq-ft

¹ $K_{observed}$ is the vertical infiltration measured in the field, before applying a factor of safety. If field testing measures a rate that is different than the vertical infiltration rate (for example, three-dimensional borehole percolation rate), then this rate must be adjusted by an acceptable method (for example, Porchet method) to yield the field estimate of vertical infiltration rate, $K_{observed}$. See Appendix VII.

Worksheet B: Simple Design Capture Volume Sizing Method

Step 1: Determine the design capture storm depth used for calculating volume				
1	Enter design capture storm depth from Figure III.1, d (inches)	$d=$	0.75	inches
2	Enter the effect of provided HSCs, d_{HSC} (inches) (Worksheet A)	$d_{HSC}=$	0.00	inches
3	Calculate the remainder of the design capture storm depth, $d_{remainder}$ (inches) (Line 1 - Line 2)	$d_{remainder}=$	0.75	inches
Step 2: Calculate the DCV				
1	Enter Project area tributary to BMP (s), A (acres)	$A=$	0.12	acres
2	Enter Project Imperviousness, imp (unitless)	$imp=$	0.74	
3	Calculate runoff coefficient, $C = (0.75 \times imp) + 0.15$	$C=$	0.71	
4	Calculate runoff volume, $V_{design} = (C \times d_{remainder} \times A \times 43560 \times (1/12))$	$V_{design}=$	232.0	cu-ft
Step 3: Design BMPs to ensure full retention of the DCV				
Step 3a: Determine design infiltration rate				
1	Enter measured infiltration rate, $K_{observed}^1$ (in/hr) (Appendix VII)	$K_{observed}=$	12	In/hr
2	Enter combined safety factor from Worksheet H, S_{total} (unitless)	$S_{total}=$	1.56	
3	Calculate design infiltration rate, $K_{design} = K_{observed} / S_{total}$	$K_{design}=$	7.68	In/hr
Step 3b: Determine minimum BMP footprint				
4	Enter drawdown time, T (max 48 hours)	$T=$	48	Hours
5	Calculate max retention depth that can be drawn down within the drawdown time (feet), $D_{max} = K_{design} \times T \times (1/12)$	$D_{max}=$	30	feet
6	Calculate minimum area required for BMP (sq-ft), $A_{min} = V_{design} / d_{max}$	$A_{min}=$	7.7	sq-ft

¹ $K_{observed}$ is the vertical infiltration measured in the field, before applying a factor of safety. If field testing measures a rate that is different than the vertical infiltration rate (for example, three-dimensional borehole percolation rate), then this rate must be adjusted by an acceptable method (for example, Porchet method) to yield the field estimate of vertical infiltration rate, $K_{observed}$. See Appendix VII.

Worksheet B: Simple Design Capture Volume Sizing Method

Step 1: Determine the design capture storm depth used for calculating volume				
1	Enter design capture storm depth from Figure III.1, d (inches)	$d=$	0.75	inches
2	Enter the effect of provided HSCs, d_{HSC} (inches) (Worksheet A)	$d_{HSC}=$	0.00	inches
3	Calculate the remainder of the design capture storm depth, $d_{remainder}$ (inches) (Line 1 - Line 2)	$d_{remainder}=$	0.75	inches
Step 2: Calculate the DCV				
1	Enter Project area tributary to BMP (s), A (acres)	$A=$	1.44	acres
2	Enter Project Imperviousness, imp (unitless)	$imp=$	0.29	
3	Calculate runoff coefficient, $C = (0.75 \times imp) + 0.15$	$C=$	0.37	
4	Calculate runoff volume, $V_{design} = (C \times d_{remainder} \times A \times 43560 \times (1/12))$	$V_{design}=$	1,450.5	cu-ft
Step 3: Design BMPs to ensure full retention of the DCV				
Step 3a: Determine design infiltration rate				
1	Enter measured infiltration rate, $K_{observed}^1$ (in/hr) (Appendix VII)	$K_{observed}=$	12	In/hr
2	Enter combined safety factor from Worksheet H, S_{total} (unitless)	$S_{total}=$	1.56	
3	Calculate design infiltration rate, $K_{design} = K_{observed} / S_{total}$	$K_{design}=$	7.68	In/hr
Step 3b: Determine minimum BMP footprint				
4	Enter drawdown time, T (max 48 hours)	$T=$	48	Hours
5	Calculate max retention depth that can be drawn down within the drawdown time (feet), $D_{max} = K_{design} \times T \times (1/12)$	$D_{max}=$	30	feet
6	Calculate minimum area required for BMP (sq-ft), $A_{min} = V_{design} / d_{max}$	$A_{min}=$	48.4	sq-ft

¹ $K_{observed}$ is the vertical infiltration measured in the field, before applying a factor of safety. If field testing measures a rate that is different than the vertical infiltration rate (for example, three-dimensional borehole percolation rate), then this rate must be adjusted by an acceptable method (for example, Porchet method) to yield the field estimate of vertical infiltration rate, $K_{observed}$. See Appendix VII.

Worksheet H: Factor of Safety and Design Infiltration Rate and Worksheet

Factor Category		Factor Description	Assigned Weight (w)	Factor Value (v)	Product (p) $p = w \times v$
A	Suitability Assessment	Soil assessment methods	0.25	1	0.25
		Predominant soil texture	0.25	1	0.25
		Site soil variability	0.25	2	0.50
		Depth to groundwater / impervious layer	0.25	1	0.25
		Suitability Assessment Safety Factor, $S_A = \Sigma p$			
B	Design	Tributary area size	0.25	1	0.25
		Level of pretreatment/ expected sediment loads	0.25	1	0.25
		Redundancy	0.25	1	0.25
		Compaction during construction	0.25	2	0.50
		Design Safety Factor, $S_B = \Sigma p$			
Combined Safety Factor, $S_{Total} = S_A \times S_B$				1.56	
Observed Infiltration Rate, inch/hr, $K_{observed}$ (corrected for test-specific bias)				12	
Design Infiltration Rate, in/hr, $K_{DESIGN} = K_{Observed} / S_{Total}$				7.68	
Supporting Data					
Briefly describe infiltration test and provide reference to test forms:					

Note: The minimum combined adjustment factor shall not be less than 2.0 and the maximum combined adjustment factor shall not exceed 9.0.

INF-7: Underground Infiltration

Underground infiltration is a vault or chamber with an open bottom that used to store runoff and percolate into the subsurface. A number of vendors offer proprietary infiltration products that allow for similar or enhanced rates of infiltration and subsurface storage while offering durable prefabricated structures. There are many varieties of proprietary infiltration BMPs that can be used for roads and parking lots, parks and open spaces, single and multi-family residential, or mixed-use and commercial uses.



Feasibility Screening Considerations

- Infiltration bays shall pass infeasible screening criteria to be considered for use.
- Underground infiltration galleries pose a potential risk of groundwater contamination; pretreatment should be used.

Opportunity Criteria

- Soils are adequate for infiltration or can be amended to provide an adequate infiltration rate.
- Appropriate for sites with limited surface space.
- Can be placed beneath roads, parking lots, parks, and athletic fields.
- Potential for groundwater contamination can be mitigated through isolation of pollutant sources, pretreatment of inflow, and/or demonstration of adequate treatment capacity of underlying soils.
- Infiltration is into native soil, or depth of engineered fill is ≤ 5 feet from the bottom of the facility to native material and infiltration into fill is approved by a geotechnical professional.
- Tributary area land uses include mixed-use and commercial, single-family and multi-family, roads and parking lots, and parks and open spaces. High pollutant land uses should not be tributary to infiltration BMPs.

OC-Specific Design Criteria and Considerations

- Placement of BMPs should observe geotechnical recommendations with respect to geological hazards (e.g. landslides, liquefaction zones, erosion, etc.) and set-backs (e.g., foundations, utilities, roadways, etc.)
- Minimum separation to mounded seasonally high groundwater of 10 feet shall be observed.
- Minimum pretreatment should be provided upstream of the infiltration facility, and water bypassing pretreatment should not be directed to the facility.
- Underground infiltration should not be used for drainage areas with high sediment production potential unless preceded by full treatment control with a BMP effective for sediment removal.
- Design infiltration rate should be determined as described in **Appendix VII**.
- Inspection ports or similar design features shall be provided to verify continued system performance and identify need for major maintenance.



For infiltration facilities beneath roads and parking areas, structural requirements should meet H-20 load requirements.

Computing Underground Infiltration Device Size

Underground infiltration devices vary by design and by proprietary designs. The sizing method selected for use must be based on the BMP type it most strongly resembles.

- For underground infiltration devices with open pore volume (e.g., vaults, crates, pipe sections, etc), sizing will be most similar to infiltration basins.
- For underground infiltration devices with pore space (e.g., aggregate reservoirs), sizing will be most similar to permeable pavement.

Additional References for Design Guidance

- Los Angeles Unified School District (LAUSD) Stormwater Technical Manual, Chapter 5:
http://www.laschools.org/employee/design/fs-studies-and-reports/download/white_paper_report_material/Storm_Water_Technical_Manual_2009-opt-red.pdf?version_id=76975850

Worksheet I: Summary of Groundwater-related Feasibility Criteria

1	Is project large or small? (as defined by Table VIII.2) circle one	Large	<u>Small</u>
2	What is the tributary area to the BMP?	A	3.58 acres
3	What type of BMP is proposed?	Infiltration	
4	What is the infiltrating surface area of the proposed BMP?	A _{BMP}	1170 sq-ft
5	What land use activities are present in the tributary area (list all) - Proposed library building - Landscape areas - Paved parking lot		
6	What land use-based risk category is applicable?	<u>L</u>	M H
7	If M or H, what pretreatment and source isolation BMPs have been considered and are proposed (describe all):		
8	What minimum separation to mounded seasonally high groundwater applies to the proposed BMP? See Section VIII.2 (circle one)	5 ft	<u>10 ft</u>
9	Provide rationale for selection of applicable minimum separation to seasonally high mounded groundwater:		
10	What is separation from the infiltrating surface to seasonally high groundwater?	SHGWT	50 ft
11	What is separation from the infiltrating surface to mounded seasonally high groundwater?	Mounded SHGWT	50 ft
12	Describe assumptions and methods used for mounding analysis:		
13	Is the site within a plume protection boundary (See Figure	Y	<u>N</u> N/A

Worksheet I: Summary of Groundwater-related Feasibility Criteria

	VIII.2)?	
14	Is the site within a selenium source area or other natural plume area (See Figure VIII.2)?	Y <input checked="" type="radio"/> N N/A
15	Is the site within 250 feet of a contaminated site?	Y <input checked="" type="radio"/> N N/A
16	If site-specific study has been prepared, provide citation and briefly summarize relevant findings:	
17	Is the site within 100 feet of a water supply well, spring, septic system?	Y <input checked="" type="radio"/> N N/A
18	Is infiltration feasible on the site relative to groundwater-related criteria?	<input checked="" type="radio"/> Y N
<p>Provide rationale for feasibility determination: Depth to groundwater is $> 10'$ and $K_{design} = 7.68 \text{ in/hr.}$</p>		

Note: if a single criterion or group of criteria would render infiltration infeasible, it is not necessary to evaluate every question in this worksheet.

Attachment F

Project Summary


Date:	12/14/2016
Project Name:	Costa Mesa Library
City / County:	Costa Mesa
State:	California
Designed By:	GT
Company:	KPFF
Telephone:	(310) 665-1540

Enter Information in
Blue Cells

Corrugated Metal Pipe Calculator

Storage Volume Required (cf):	7,950
Limiting Width (ft):	30.00
Effective Depth Below Asphalt (ft):	9.00
Solid or Perforated Pipe:	Perforated
Shape Or Diameter:	96
Spacing between Barrels (ft):	3.00
Stone Width Around Perimeter of System (ft):	0
Depth A: Porous Stone Above Pipe (in):	12
Depth C: Porous Stone Below Pipe (in):	12
Stone Porosity (0 to 40%):	20

50.27 ft² Pipe Area



System Sizing

Use Custom Layout (at right) for layout adjustment

Pipe Storage:	6,786 cf	
Porous Stone Storage:	1,343 cf	
Total Storage Provided:	8,129 cf	102.2% Of Required Storage
Number of Barrels:	3 barrels	
Length Per Barrel:	45.00 ft	
Rectangular Footprint (W x L):	30. ft x 45. ft	

CONTECH Materials

Total CMP Footage:	135 ft
Approximate Total Pieces:	6 pcs
Approximate Coupling Bands:	3 bands
Approximate Truckloads:	3 trucks

Construction Quantities**

Total Excavation:	450 cy
Porous Stone Backfill For Storage:	249 cy Stone
Backfill to Grade Excluding Stone:	-50 cy Fill

**Construction quantities are approximate and should be verified upon final design

Custom Layout

To adjust layout, enter desired barrel length in the light blue boxes below.

Excess Footage = 0

Barrel 12	<input type="text" value="0"/>	0				
Barrel 11	<input type="text" value="0"/>	0				
Barrel 10	<input type="text" value="0"/>	0				
Barrel 9	<input type="text" value="0"/>	0				
Barrel 8	<input type="text" value="0"/>	0				
Barrel 7	<input type="text" value="0"/>	0				
Barrel 6	<input type="text" value="0"/>	0				
Barrel 5	<input type="text" value="0"/>	0				
Barrel 4	<input type="text" value="0"/>	0				
Barrel 3	<input type="text" value="45"/>	45	45			
Barrel 2	<input type="text" value="45"/>	45	45			
Barrel 1	<input type="text" value="45"/>	45	45			

0 10 20 30 40 50